HYDRAULIC LIFTERS
DESCRIPTION 110
REMOVAL 110
CLEANING 110
INSPECTION 110
INSTALLATION 111
PISTON & CONNECTING ROD
DESCRIPTION 111
STANDARD PROCEDURE - PISTON FITTING . 111
REMOVAL 112
INSTALLATION 113
PISTON RINGS
STANDARD PROCEDURE - PISTON RING FITTING 114
VIBRATION DAMPER
REMOVAL 117
INSTALLATION 117
STRUCTURAL SUPPORT
REMOVAL 117
INSTALLATION 117
FRONT MOUNT
REMOVAL 118
INSTALLATION 119
REAR MOUNT
REMOVAL 119
INSTALLATION 119
LUBRICATION
DESCRIPTION 120
OPERATION 120
DIAGNOSIS AND TESTING
DIAGNOSIS AND TESTING - ENGINE OIL PRESSURE 122
DIAGNOSIS AND TESTING - ENGINE OIL LEAK 122
OIL
STANDARD PROCEDURE - ENGINE OIL SERVICE 123
OIL FILTER
REMOVAL 124
INSTALLATION 124
OIL PAN
DESCRIPTION 124
REMOVAL 124
INSTALLATION 125
ENGINE OIL PRESSURE SENSOR
DESCRIPTION 126
OPERATION 126
OIL PUMP
REMOVAL 126
INSTALLATION 126
VALVE TIMING
STANDARD PROCEDURE - VALVE TIMING . . 127
TIMING BELT / CHAIN COVER(S)
REMOVAL 127
INSTALLATION 127
TIMING BELT/CHAIN AND SPROCKETS
REMOVAL 128
INSTALLATION 129
INTAKE MANIFOLD
DESCRIPTION 129
DIAGNOSIS AND TESTING - INTAKE MANIFOLD LEAKAGE 129
REMOVAL 129
INSTALLATION 130
EXHAUST MANIFOLD
DESCRIPTION 131
REMOVAL 131