ENGINE 4.0L (Continued)

CONDITION	POSSIBLE CAUSES	CORRECTION
ENGINE CRANKS BUT WILL NOT START	1. No spark	1. Check for spark. (Refer to 8 - ELECTRICAL/IGNITION CONTROL - SPECIFICATIONS), for correct procedures.
	2. No fuel	2. Perform fuel pressure test (Refer to 14 - FUEL SYSTEM/FUEL DELIVERY/FUEL PUMP - DIAGNOSIS AND TESTING), and if necessary, inspect fuel injector(s) and driver circuits. (Refer to 14 - FUEL SYSTEM/FUEL INJECTION/ FUEL INJECTOR - DIAGNOSIS AND TESTING), for correct procedures.
	3. Low or no engine compression	3. Perform cylinder compression pressure test. (Refer to 9 - ENGINE - DIAGNOSIS AND TESTING).
ENGINE LOSS OF POWER	1. Worn or burned distributor rotor	1. Install new distributor rotor
	2. Worn camshaft position sensor shaft	2. Remove and repair camshaft position sensor. (Refer to 8 - ELECTRICAL/IGNITION CONTROL/ CAMSHAFT POSITION SENSOR - REMOVAL).
	3. Worn or incorrect gapped spark plugs	3. Clean plugs and set gap. (Refer to 8 - ELECTRICAL/IGNITION CONTROL/SPARK PLUG - CLEANING).
	4. Dirt or water in fuel system	4. Clean system and replace fuel filter
	5. Faulty fuel pump	5. Install new fuel pump
	6. Incorrect valve timing	6. Correct valve timing
	7. Blown cylinder head gasket	7. Install new cylinder head gasket
	8. Low compression	8. Test cylinder compression. (Refer to 9 - ENGINE - DIAGNOSIS AND TESTING).
	9. Burned, warped, or pitted valves	9. Install/Reface valves as necessary
	10. Plugged or restricted exhaust system	10. Install new parts as necessary
	11. Faulty ignition coil rail	11. Test and replace, as necessary. (Refer to 8 - ELECTRICAL/ IGNITION CONTROL/COIL RAIL - REMOVAL).
ENGINE STALLS OR ROUGH IDLE	1. Carbon build-up on throttle plate	1. Remove throttle body and de-carbon. (Refer to 14 - FUEL SYSTEM/FUEL INJECTION/ THROTTLE BODY - REMOVAL) for correct procedure.