ENGINE 4.0L (Continued)

CONDITION	POSSIBLE CAUSES	CORRECTION
	2. Engine idle speed too low	2. Check Idle Air Control circuit.
	3. Worn or incorrectly gapped spark plugs	3. Replace or clean and re-gap spark plugs. (Refer to 8 - ELECTRICAL/IGNITION CONTROL/ SPARK PLUG - CLEANING)
	4. Faulty coil rail	4. Test and replace, if necessary. (Refer to 8 - ELECTRICAL/ IGNITION CONTROL/COIL RAIL - REMOVAL)
	5. Intake manifold vacuum leak	5. Inspect intake manifold gasket and vacuum hoses. Replace if necessary. (Refer to 9 - ENGINE/ MANIFOLDS/INTAKE MANIFOLD - DIAGNOSIS AND TESTING).
ENGINE MISSES ON ACCELERATION	1. Worn or incorrectly gapped spark plugs	1. Replace spark plugs or clean and set gap.
	2. Spark plug cables defective or crossed	2. Replace spark plug cables.
	3. Dirt in fuel system	3. Clean fuel system
	4. Burned, warped or pitted valves	4. Install new valves
	5. Faulty coil rail	5. Test and replace as necessary. (Refer to 8 - ELECTRICAL/ IGNITION CONTROL/COIL RAIL - REMOVAL)