FUEL INJECTION

TABLE OF CONTENTS

page

FUEL INJECTION
DESCRIPTION 22
SPECIFICATIONS
TORQUE - FUEL INJECTION 22
ACCELERATOR PEDAL
REMOVAL 23
INSTALLATION 23
CRANKSHAFT POSITION SENSOR
DESCRIPTION 23
OPERATION 23
REMOVAL 24
INSTALLATION 25
FUEL INJECTOR
DESCRIPTION 27
OPERATION
OPERATION - PCM OUTPUT 27
OPERATION - FUEL INJECTOR 27
REMOVAL 27
INSTALLATION 28
FUEL PUMP RELAY
DESCRIPTION 28
OPERATION 28
REMOVAL 28
INSTALLATION 28
IDLE AIR CONTROL MOTOR
DESCRIPTION 28
OPERATION 28
REMOVAL 29
INSTALLATION 30
INTAKE AIR TEMPERATURE SENSOR
DESCRIPTION 30

page

OPERATION 30
REMOVAL 30
INSTALLATION 31
MAP SENSOR
DESCRIPTION 31
OPERATION 31
REMOVAL 32
INSTALLATION 33
O2 HEATER RELAY
DESCRIPTION 34
OPERATION 34
REMOVAL 34
INSTALLATION 34
O2 SENSOR
DESCRIPTION 34
OPERATION 34
REMOVAL 35
INSTALLATION 36
THROTTLE BODY
DESCRIPTION 36
OPERATION 36
REMOVAL 37
INSTALLATION 37
THROTTLE CONTROL CABLE
REMOVAL 38
INSTALLATION 40
THROTTLE POSITION SENSOR
DESCRIPTION 40
OPERATION 40
REMOVAL 40
INSTALLATION 41