STEERING (Continued)

CONDITION	POSSIBLE CAUSE	CORRECTION
STEERING WHEEL DOES NOT WANT TO RETURN TO CENTER POSITION	1. Tire pressure.	1. Adjust tire pressure.
	2. Wheel alignment.	2. Align front end.
	3. Lack of lubrication.	3. Inspect and lubricate steering and suspension compnents.
	4. High friction in steering gear.	4. Test and adjust as necessary.
	5. Ball joints binding.	5. Inspect and repair as necessary.

NOTE:
Some roads will cause a vehicle to drift, due to the crown in the road.

LOOSE STEERING AND VEHICLE LEADS/DRIFTS

CONDITION	POSSIBLE CAUSE	CORRECTION
EXCESSIVE PLAY IN STEERING WHEEL	1. Worn or loose suspension or steering components.	1. Repair as necessary.
	2. Worn or loose wheel bearings.	2. Repair as necessary.
	3. Steering gear mounting.	3. Tighten gear mounting bolts to specification.
	4. Gear out of adjustment.	4. Adjust gear to specification.
	5. Worn or loose steering coupler.	5. Repair as necessary.
VEHICLE PULLS TO ONE SIDE DURING BRAKING	1. Tire Pressure.	1. Adjust tire pressure.
	2. Air in brake hydraulics system.	2. Bleed brake system.
	3. Worn brake components.	3. Repair as necessary.
VEHICLE LEADS OR DRIFTS FROM STRAIGHT AHEAD DIRECTION ON UNCROWNED ROAD.	1. Tire pressure.	1. Adjust tire pressure.
	2. Radial tire lead.	2. Cross front tires.
	3. Brakes dragging.	3. Repair as necessary.
	4. Wheel alignment.	4. Align vehicle.
	5. Weak or broken spring.	5. Replace spring.
	6. Loose or worn steering/ suspension components.	6. Repair as necessary.
	7. Cross caster out of spec.	7. Adjust or replace axle as necessary.

DIAGNOSIS AND TESTING - POWER STEERING FLOW AND PRESSURE

The following procedure is used to test the operation of the power steering system on the vehicle. This test will provide the gallons per minute (GPM) or flow rate of the power steering pump along with the maximum relief pressure. Perform test any time a power steering system problem is present. This test will determine if the power steering pump or power steering gear is not functioning properly. The following pressure and flow test is performed using Power Steering Analyzer Tool 6815 (Fig. 4) and Adapter kit 6893.

FLOW AND PRESSURE TEST

(1) Check the power steering belt to ensure it is in good condition and adjusted properly.

(2) Connect pressure gauge hose from the Power Steering Analyzer to Tube 6865.

(3) Connect Adapter 6826 to Power Steering Analyzer test valve end.