COLUMN

TABLE OF CONTENTS

	page
COLUMN	
DESCRIPTION	6
OPERATION - SERVICE PRECAUTIONS	6
REMOVAL	6
INSTALLATION	8
SPECIFICATIONS TORQUE CHART	9
IGNITION SWITCH	
DESCRIPTION	9
DIAGNOSIS AND TESTING - IGNITION SWITCH	9
REMOVAL	9
INSTALLATION	10
KEY-IN IGNITION SWITCH	
DESCRIPTION	10
DIAGNOSIS AND TESTING - KEY-IN IGNITION SWITCH	10
KEY CYLINDER	
REMOVAL	11
INSTALLATION	11
STEERING WHEEL	
REMOVAL	11
INSTALLATION	12

COLUMN

DESCRIPTION

NOTE: The steering column on vehicles with an automatic transmission may not be equipped with an internal locking shaft that allows the ignition key cylinder to be locked with the key. Alternative methods of locking the steering wheel for service will have to be used.

The standard non-tilt and tilt steering column has been designed to be serviced as an assembly. The column is connected to the steering gear with an upper and lower shaft. The lower shaft has a support bearing mounted to a bracket. The bracket mounts to the frame rail with two bolts. These shafts and bearing are serviceable. The key cylinder, switches, clock spring, trim shrouds and steering wheel are serviced separately.

OPERATION - SERVICE PRECAUTIONS

Safety goggles should be worn at all times when working on steering columns.

To service the steering wheel, switches or airbag, refer to Electrical - Restraints and follow all WARNINGS and CAUTIONS.

WARNING: THE AIRBAG SYSTEM IS A SENSITIVE, COMPLEX ELECTRO-MECHANICAL UNIT. BEFORE ATTEMPTING TO DIAGNOSE, REMOVE OR INSTALL THE AIRBAG SYSTEM COMPONENTS YOU MUST FIRST DISCONNECT AND ISOLATE THE BATTERY NEGATIVE (GROUND) CABLE. THEN WAIT TWO MINUTES FOR THE SYSTEM CAPACITOR TO DISCHARGE. FAILURE TO DO SO COULD RESULT IN ACCIDENTAL DEPLOYMENT OF THE AIRBAG AND POSSIBLE PERSONAL INJURY. THE FASTENERS, SCREWS, AND BOLTS, ORIGINALLY USED FOR THE AIRBAG COMPONENTS, HAVE SPECIAL COATINGS AND ARE SPECIFICALLY DESIGNED FOR THE AIRBAG SYSTEM. THEY MUST NEVER BE REPLACED WITH ANY SUBSTITUTES. ANYTIME A NEW FASTENER IS NEEDED, REPLACE WITH THE CORRECT FASTENERS PROVIDED IN THE SERVICE PACKAGE OR FASTENERS LISTED IN THE PARTS BOOKS.

REMOVAL

(1) Position front wheels **straight ahead.**

(2) Remove and isolate the negative ground cable from the battery.

(3) Remove the airbag, (Refer to 8 - ELECTRICAL/ RESTRAINTS/DRIVER AIRBAG - REMOVAL).

NOTE: If equipped with cruise control, disconnect clock spring harness from the cruise switch harness on the steering wheel.

(4) Remove the steering wheel with an appropriate puller (Fig. 1).

NOTE: Ensure the puller jaws are seated in the pockets (Fig. 2) of the steering wheel armature.

(5) Turn ignition cylinder to the on position and remove cylinder by pressing release through lower shroud access hole (Fig. 3) (Refer to 19 - STEERING/ COLUMN/LOCK CYLINDER HOUSING - REMOVAL).