LINKAGE

TABLE OF CONTENTS

page

LINKAGE
DESCRIPTION 17
STANDARD PROCEDURE
STANDARD PROCEDURE - LUBRICATION . . 17
STANDARD PROCEDURE - STEERING LINKAGE 17
SPECIFICATIONS
TORQUE CHART 18
SPECIAL TOOLS
STEERING LINKAGE 18
DAMPER
REMOVAL 18
INSTALLATION 18
DRAG LINK
REMOVAL 19
INSTALLATION 19
PITMAN ARM
REMOVAL 19
INSTALLATION 19
TIE ROD END
REMOVAL 19
INSTALLATION 19

LINKAGE

DESCRIPTION

The steering linkage consists of a pitman arm, drag link, tie rod, and steering dampener (Fig. 1). Adjustment sleeves are used on the tie rod and drag link for toe and steering wheel alignment.

The service procedures and torque specifications are the same for LHD and RHD vehicles.



Fig. 1 Steering Linkage

1 - COTTER PIN
2 - NUT
3 - DAMPENER
4 - PITMAN ARM
5 - WASHER
6 - TIE ROD
7 - DRAG LINK

STANDARD PROCEDURE

STANDARD PROCEDURE - LUBRICATION

Periodic lubrication of the steering system components is required. Refer to Lubrication And Maintenance for the recommended maintenance schedule.

The following components must be lubricated:

- Tie rod ends
- Drag link

STANDARD PROCEDURE - STEERING LINKAGE

The tie rod end and ball stud seals should be inspected during all oil changes. If a seal is damaged, it should be replaced. Before installing a new seal, inspect ball stud at the throat opening. Check for lubricant loss, contamination, ball stud wear or corrosion. If these conditions exist, replace the tie rod. A replacement seal can be installed if lubricant is in good condition. Otherwise, a complete replacement ball stud end should be installed.

CAUTION: If any steering components are replaced or serviced an alignment must be performed, to ensure the vehicle meets all alignment specifications.

CAUTION: Components attached with a nut and cotter pin must be torqued to specification. Then if the slot in the nut does not line up with the cotter pin hole, tighten nut until it is aligned. Never loosen the nut to align the cotter pin hole.