PUMP

TABLE OF CONTENTS

page

PUMP
DESCRIPTION 20
OPERATION 20
DIAGNOSIS AND TESTING - PUMP LEAKAGE . 20
STANDARD PROCEDURE - POWER STEERING PUMP - INITIAL OPERATION 20
REMOVAL
REMOVAL - 4.0L 21
REMOVAL - 2.4L 21
INSTALLATION
INSTALLATION - 4.0L 21
INSTALLATION - 2.4L 22
SPECIFICATIONS
TORQUE CHART 23
SPECIAL TOOLS
POWER STEERING PUMP 23
HOSES
DESCRIPTION
DESCRIPTION - PRESSURE LINE 24
DESCRIPTION - RETURN LINE 24
OPERATION
OPERATION - PRESSURE LINE 24
OPERATION - RETURN LINE 24
FLUID
DESCRIPTION 24
STANDARD PROCEDURE - POWER STEERING FLUID LEVEL CHECKING 24
POWER STEERING PRESSURE SWITCH
DESCRIPTION 24
OPERATION 24
REMOVAL 25
INSTALLATION 25
PULLEY
REMOVAL 25
INSTALLATION 25
RESERVOIR
REMOVAL
REMOVAL - 4.0L 26
REMOVAL - 2.4L 26
INSTALLATION
INSTALLATION - 4.0L 26
INSTALLATION - 2.4L 26

PUMP

DESCRIPTION

Hydraulic pressure for the power steering system is provided by a belt driven power steering pump (Fig. 1). The pump shaft has a pressed-on high strength plastic drive pulley that is belt driven by the crankshaft pulley. The reservoir is attached to the pump body with spring clips on the 4.0L engine. A remote pump reservoir is used on the 2.4L engine mounted to the fan shroud. The power steering pump is connected to the steering gear by the pressure and return hoses.

OPERATION

The power steering pump is a constant flow rate and displacement, vane-type pump. The pump internal parts operate submerged in fluid. The flow control orifice is part of the high pressure line fitting. The pressure relief valve inside the flow control valve limits the pump pressure.

NOTE: Power steering pumps have different pressure rates and are not interchangeable with other pumps.

DIAGNOSIS AND TESTING - PUMP LEAKAGE

(1) Possible areas of pump leakage (Fig. 2).

STANDARD PROCEDURE - POWER STEERING PUMP - INITIAL OPERATION

WARNING: THE FLUID LEVEL SHOULD BE CHECKED WITH ENGINE OFF TO PREVENT INJURY FROM MOVING COMPONENTS.

CAUTION: MOPAR® ATF+4 is to be used in the power steering system. No other power steering or automatic transmission fluid is to be used in the system. Damage may result to the power steering pump and system if any other fluid is used, and do not overfill.

Wipe filler cap clean, then check the fluid level. The dipstick should indicate **COLD** when the fluid is at normal ambient temperature.

(1) Fill the pump fluid reservoir to the proper level and let the fluid settle for at least two minutes.

(2) Start the engine and let run for a few seconds then turn engine off.