AUTOMATIC TRANSMISSION - 42RLE

TABLE OF CONTENTS

page

AUTOMATIC TRANSMISSION - 42RLE
DESCRIPTION 38
OPERATION 40
DIAGNOSIS AND TESTING
DIAGNOSIS AND TESTING - AUTOMATIC TRANSMISSION 46
DIAGNOSIS AND TESTING - ROAD TEST . . . 46
DIAGNOSIS AND TESTING - HYDRAULIC PRESSURE TESTS 47
DIAGNOSIS AND TESTING - CLUTCH AIR PRESSURE TESTS 50
DIAGNOSIS AND TESTING - FLUID LEAKAGE 50
STANDARD PROCEDURE - ALUMINUM THREAD REPAIR 51
REMOVAL 51
DISASSEMBLY 53
ASSEMBLY 69
INSTALLATION 85
SCHEMATICS AND DIAGRAMS - 42RLE TRANSMISSION 88
SPECIFICATIONS
42RLE AUTOMATIC TRANSMISSION 101
SPECIAL TOOLS
42RLE AUTOMATIC TRANSMISSION 103
ACCUMULATOR
DESCRIPTION 106
OPERATION 106
ADAPTER HOUSING SEAL
REMOVAL 106
INSTALLATION 106
BEARINGS
ADJUSTMENTS
BEARING ADJUSTMENT PROCEDURES . . . 106
BRAKE TRANSMISSION SHIFT INTERLOCK MECHANISM
DESCRIPTION 107
OPERATION 108
REMOVAL 108
INSTALLATION 108
ADJUSTMENTS
ADJUSTMENT - BRAKE TRANSMISSION SHIFT INTERLOCK CABLE 108
DRIVING CLUTCHES
DESCRIPTION 109
OPERATION 109

page

FLUID AND FILTER
DIAGNOSIS AND TESTING
DIAGNOSIS AND TESTING - CAUSES OF BURNT FLUID 110
EFFECTS OF INCORRECT FLUID LEVEL . . 110
FLUID CONTAMINATION 110
STANDARD PROCEDURE
STANDARD PROCEDURE - FLUID LEVEL CHECK. 111
STANDARD PROCEDURE - FLUID/FILTER SERVICE 111
STANDARD PROCEDURE - TRANSMISSION FILL 112
GEARSHIFT CABLE
REMOVAL 113
INSTALLATION 113
HOLDING CLUTCHES
DESCRIPTION 114
OPERATION 114
INPUT CLUTCH ASSEMBLY
DISASSEMBLY 114
ASSEMBLY 121
INPUT SPEED SENSOR
DESCRIPTION 131
OPERATION 131
REMOVAL 131
INSTALLATION 132
OIL PUMP
DESCRIPTION 132
OPERATION 132
DISASSEMBLY 132
ASSEMBLY 133
OUTPUT SPEED SENSOR
DESCRIPTION 134
OPERATION 134
REMOVAL 134
INSTALLATION 134
OVERDRIVE SWITCH
DESCRIPTION 135
OPERATION 135
REMOVAL 135
INSTALLATION 135
PLANETARY GEARTRAIN
DESCRIPTION 136
OPERATION 136
OIL PUMP SEAL
REMOVAL 136
INSTALLATION 136