CONTROLS

TABLE OF CONTENTS

page

A/C COMPRESSOR CLUTCH
DESCRIPTION . . . 11
OPERATION . . . 11
DIAGNOSIS AND TESTING
A/C COMPRESSOR CLUTCH COIL . . . 11
STANDARD PROCEDURE
DIODE REPLACEMENT . . . 12
A/C CLUTCH INSPECTION . . . 12
A/C CLUTCH BREAK-IN . . . 12
REMOVAL . . . 12
INSTALLATION . . . 14
A/C CLUTCH RELAY
DESCRIPTION . . . 15
OPERATION . . . 15
REMOVAL . . . 16
INSTALLATION . . . 16
A/C HEATER CONTROL
DESCRIPTION . . . 16
DIAGNOSIS AND TESTING
VACUUM CONTROL SYSTEM . . . 17
REMOVAL . . . 21
INSTALLATION . . . 21
A/C HIGH PRESSURE SWITCH
DESCRIPTION . . . 21
OPERATION . . . 22
DIAGNOSIS AND TESTING
A/C HIGH PRESSURE SWITCH . . . 22
REMOVAL . . . 22
INSTALLATION . . . 22
A/C LOW PRESSURE SWITCH
DESCRIPTION . . . 23
OPERATION . . . 23
DIAGNOSIS AND TESTING
A/C LOW PRESSURE SWITCH . . . 23
REMOVAL . . . 24
INSTALLATION . . . 24
A/C PRESSURE TRANSDUCER
DESCRIPTION . . . 24
OPERATION . . . 24
DIAGNOSIS AND TESTING
A/C PRESSURE TRANSDUCER . . . 25
REMOVAL . . . 25
INSTALLATION . . . 25

page

BLEND DOOR ACTUATOR
DESCRIPTION . . . 26
OPERATION . . . 26
REMOVAL . . . 26
INSTALLATION . . . 27
BLOWER MOTOR RELAY
DESCRIPTION . . . 27
OPERATION . . . 27
REMOVAL . . . 28
INSTALLATION . . . 28
BLOWER MOTOR RESISTOR
DESCRIPTION . . . 28
OPERATION . . . 28
DIAGNOSIS AND TESTING
BLOWER MOTOR RESISTOR . . . 29
REMOVAL . . . 29
INSTALLATION . . . 30
BLOWER MOTOR SWITCH
DESCRIPTION . . . 30
OPERATION . . . 30
DIAGNOSIS AND TESTING
BLOWER MOTOR SWITCH . . . 30
REMOVAL . . . 31
INSTALLATION . . . 31
MODE DOOR ACTUATORS
DESCRIPTION . . . 31
REMOVAL . . . 32
INSTALLATION . . . 32
RECIRCULATION DOOR ACTUATOR
DESCRIPTION . . . 33
REMOVAL . . . 33
INSTALLATION . . . 34
VACUUM CHECK VALVE
DESCRIPTION . . . 34
OPERATION . . . 34
REMOVAL . . . 35
INSTALLATION . . . 35
VACUUM RESERVOIR
DESCRIPTION . . . 35
OPERATION . . . 35
REMOVAL . . . 36
INSTALLATION . . . 36