senger compartment. Tighten the bolt to 3 N·m (27 in. lbs.).

(3) Install the defroster duct onto the top of the HVAC housing.

(4) Install the two push-nuts that secure the defroster duct to the dash panel in the passenger compartment.

(5) Install the five nuts that secure the HVAC housing to the dash panel in the engine compartment. Tighten the nuts to 6 N·m (53 in. lbs.).

(6) If the battery was repositioned during the removal procedure, position the battery and tighten the hold-downs (Refer to 8 - ELECTRICAL/BATTERY SYSTEM/BATTERY - INSTALLATION).

(7) Connect the HVAC system vacuum supply line connector to the tee fitting near the heater core tubes.

(8) Unplug or remove the tape from the heater core tubes and connect the heater hoses to the heater core tubes.

(9) If the vehicle is not equipped with A/C, go to Step 15. If the vehicle is equipped with A/C, unplug or remove the tape from the liquid and suction line fittings and both evaporator tubes.

(10) Lubricate new rubber O-ring seals with clean refrigerant oil and install them on the liquid and suction line fittings.

(11) Connect the A/C liquid and suction lines to the A/C evaporator (Refer to 24 - HEATING & AIR CONDITIONING/PLUMBING/REFRIGERANT LINE COUPLER - INSTALLATION).

(12) Install the instrument panel (Refer to 23 - BODY/INSTRUMENT PANEL/INSTRUMENT PANEL ASSEMBLY - INSTALLATION).

(13) Evacuate the refrigerant system (Refer to 24 - HEATING & AIR CONDITIONING/PLUMBING - STANDARD PROCEDURE - REFRIGERANT SYSTEM EVACUATE).

(14) Charge the refrigerant system (Refer to 24 - HEATING & AIR CONDITIONING/PLUMBING - STANDARD PROCEDURE - REFRIGERANT SYSTEM CHARGE).

(15) Reconnect the negative battery cable.

(16) If the heater core is being replaced, flush the cooling system (Refer to 7 - COOLING - STANDARD PROCEDURE - COOLING SYSTEM CLEANING/ REVERSE FLUSHING).

(17) Refill the engine cooling system (Refer to 7 - COOLING - STANDARD PROCEDURE - COOLING SYSTEM REFILL).

AIR INLET HOUSING

NOTE: The recirculation-air door and actuator are used only on models equipped with A/C.

NOTE: If the foam seal on the air inlet housing is deformed or damaged, it must be replaced.

(1) Position the air inlet housing onto the top of the HVAC housing.

(2) Install the five screws that secure the air inlet housing to the HVAC housing. Tighten the screws to 2 N·m (17 in. lbs.).

(3) If equipped, connect the HVAC vacuum harness connector to the recirculation door actuator.

(4) Install the HVAC housing (Refer to 24 - HEATING & AIR CONDITIONING/DISTRIBUTION/HVAC HOUSING - INSTALLATION).

INSTRUMENT PANEL DEMISTER DUCTS

REMOVAL

WARNING: On vehicles equipped with airbags, disable the airbag system before attempting any steering wheel, steering column, or instrument panel component diagnosis or service. Disconnect and isolate the battery negative (ground) cable, then wait two minutes for the airbag system capacitor to discharge before performing further diagnosis or service. This is the only sure way to disable the airbag system. Failure to take the proper precautions could result in accidental airbag deployment and possible personal injury or death.

NOTE: The two demister ducts can be serviced without removing the instrument panel. However, if either of the demister outlets require servicing, the instrument panel must be removed.

DEMISTER DUCTS

(1) Disconnect and isolate the negative battery cable.

(2) To gain access to the passenger side demister duct, remove the glove box from the instrument panel (Refer to 23 - BODY/INSTRUMENT PANEL/ GLOVE BOX - REMOVAL).

(3) To gain access to the driver side demister duct remove the top cover, knee blocker and instrument cluster from the instrument panel (Refer to 23 - BODY/INSTRUMENT PANEL/INSTRUMENT PANEL TOP COVER - REMOVAL), (Refer to 23 - BODY/INSTRUMENT PANEL/KNEE BLOCKER - REMOVAL) and (Refer to 8 - ELECTRICAL/INSTRUMENT CLUSTER - REMOVAL).

(4) Reach through the glove box opening and/or the cluster opening of the instrument panel and dis-