DEMISTER DUCTS

(1) Reach through the glove box opening and/or the cluster opening of the instrument panel to connect the demister ducts to the demister outlets and the defroster duct as necessary.

(2) If removed, install the top cover, knee blocker and instrument cluster (Refer to 23 - BODY/INSTRUMENT PANEL/INSTRUMENT PANEL TOP COVER - INSTALLATION), (Refer to 23 - BODY/INSTRUMENT PANEL/KNEE BLOCKER - INSTALLATION) and (Refer to 8 - ELECTRICAL/INSTRUMENT CLUSTER - INSTALLATION).

(3) If removed, install the glove box (Refer to 23 - BODY/INSTRUMENT PANEL/GLOVE BOX - INSTALLATION).

(4) Reconnect the negative battery cable.

DEMISTER OUTLETS

(1) Position the demister outlets into the instrument panel as necessary.

(2) Install the screw that secures each demister outlet to the instrument panel duct as necessary.

(3) Connect the demister ducts to the demister outlets as necessary.

(4) Install the instrument panel assembly (Refer to 23 - BODY/INSTRUMENT PANEL/INSTRUMENT PANEL ASSEMBLY - INSTALLATION).

INSTRUMENT PANEL DUCTS

REMOVAL

WARNING: On vehicles equipped with airbags, disable the airbag system before attempting any steering wheel, steering column, or instrument panel component diagnosis or service. Disconnect and isolate the battery negative (ground) cable, then wait two minutes for the airbag system capacitor to discharge before performing further diagnosis or service. This is the only sure way to disable the airbag system. Failure to take the proper precautions could result in accidental airbag deployment and possible personal injury or death.

NOTE: The air ducts for the instrument panel outlets are integral to each other and cannot be serviced separately.

NOTE: Take the proper precautions to protect the front face of the instrument panel from cosmetic damage while performing this procedure.

(1) Disconnect and isolate the negative battery cable.

(2) Remove the instrument panel and place it on a workbench (Refer to 23 - BODY/INSTRUMENT PANEL/INSTRUMENT PANEL ASSEMBLY - REMOVAL).

(3) Remove the center bezel from the instrument panel (Refer to 23 - BODY/INSTRUMENT PANEL/INSTRUMENT PANEL CENTER BEZEL - REMOVAL).

(4) Remove the accessory switch bezel, A/C-heater control, radio and radio rear support bracket from the instrument panel (Refer to 23 - BODY/INSTRUMENT PANEL/ACCESSORY SWITCH BEZEL - REMOVAL), (Refer to 24 - HEATING & AIR CONDITIONING/CONTROLS/A/C HEATER CONTROL - REMOVAL) and (Fig. 39) (Refer to 8 - ELECTRICAL/AUDIO/RADIO - REMOVAL).

(5) Remove the demister ducts and the demister outlets (Refer to 24 - HEATING & AIR CONDITIONING/DISTRIBUTION/INSTRUMENT PANEL DEMISTER DUCTS - REMOVAL).

(6) Disconnect the instrument panel wire harness connectors from the left and right side courtesy lamps located at the bottom of the instrument panel.

(7) Disengage the instrument panel wire harness retainers from the instrument panel duct and position the wire harness out of the way.

(8) Remove the ten screws that secure the instrument panel duct to the instrument panel and remove the duct.