PLUMBING

TABLE OF CONTENTS

page

PLUMBING
DESCRIPTION . . . 58
OPERATION . . . 58
WARNINGS . . . 58
CAUTIONS . . . 58
DIAGNOSIS AND TESTING
REFRIGERANT SYSTEM LEAKS . . . 59
STANDARD PROCEDURE
REFRIGERANT SYSTEM SERVICE EQUIPMENT . . . 60
REFRIGERANT SYSTEM CHARGE LEVEL . . 61
REFRIGERANT SYSTEM RECOVERY . . . 62
REFRIGERANT SYSTEM EVACUATE . . . 62
REFRIGERANT SYSTEM CHARGE . . . 63
A/C COMPRESSOR
DESCRIPTION
A/C COMPRESSOR . . . 64
HIGH PRESSURE RELIEF VALVE . . . 64
OPERATION
A/C COMPRESSOR . . . 64
HIGH PRESSURE RELIEF VALVE . . . 64
DIAGNOSIS AND TESTING
A/C COMPRESSOR NOISE . . . 64
REMOVAL
2.4L ENGINE . . . 65
4.0L ENGINE . . . 66
INSTALLATION
2.4L ENGINE . . . 67
4.0L ENGINE . . . 67
A/C CONDENSER
DESCRIPTION . . . 68
OPERATION . . . 68
REMOVAL . . . 68
INSTALLATION . . . 69
A/C DISCHARGE LINE
DESCRIPTION . . . 70
REMOVAL
2.4L ENGINE . . . 70
4.0L ENGINE . . . 71
INSTALLATION
2.4L ENGINE . . . 71
4.0L ENGINE . . . 72
A/C EVAPORATOR
DESCRIPTION . . . 72

page

OPERATION . . . 73
REMOVAL . . . 73
INSTALLATION . . . 73
A/C ORIFICE TUBE
DESCRIPTION . . . 73
OPERATION . . . 74
DIAGNOSIS AND TESTING
A/C ORIFICE TUBE . . . 74
ACCUMULATOR
DESCRIPTION . . . 74
OPERATION . . . 74
REMOVAL . . . 75
INSTALLATION . . . 76
HEATER CORE
DESCRIPTION . . . 76
OPERATION . . . 76
REMOVAL . . . 77
INSTALLATION . . . 77
LIQUID LINE
DESCRIPTION . . . 77
REMOVAL . . . 77
INSTALLATION . . . 78
REFRIGERANT
DESCRIPTION . . . 79
OPERATION . . . 79
REFRIGERANT LINE COUPLER
DESCRIPTION . . . 79
OPERATION . . . 80
REMOVAL . . . 80
INSTALLATION . . . 81
REFRIGERANT OIL
DESCRIPTION . . . 81
OPERATION . . . 81
STANDARD PROCEDURE
REFRIGERANT OIL LEVEL . . . 81
SERVICE PORT VALVE CORE
DESCRIPTION . . . 82
REMOVAL . . . 82
INSTALLATION . . . 82
SUCTION LINE
DESCRIPTION . . . 83
REMOVAL . . . 83
INSTALLATION . . . 84