A/C CONDENSER (Continued)

(3) Align the radiator mounting brackets to the grille panel and install the six bolts that secure the radiator to the grille panel. Tighten the bolts to 8 N·m (72 in. lbs.).

(4) Raise and support the vehicle.

(5) Position the lower condenser/radiator air seal out of the way and install the two bolts that secure the lower condenser mounting bracket to the bottom of the grille panel. Tighten the bolts to 5 N·m (44 in. lbs.).

(6) Lower the vehicle.

(7) Remove the tape or plugs from the discharge and liquid line fittings and the condenser ports.

(8) Lubricate new rubber O-ring seals with clean refrigerant oil and install them onto the discharge and liquid line fittings. Use only the specified O-rings as they are made of a special material for the R-134a system. Use only refrigerant oil of the type recommended for the A/C compressor in the vehicle.

(9) Install the discharge and liquid lines onto the condenser tapping block.

(10) Install the nuts that secures the discharge and liquid lines to the condenser tapping block. Tighten the nuts to 12 N·m (105 in. lbs.).

(11) If equipped, install the upper condenser/radiator air seal.

(12) Install the radiator cooling fan and fan shroud (Refer to 7 - COOLING/ENGINE/FAN DRIVE VISCOUS CLUTCH - INSTALLATION).

(13) Connect the upper radiator hose to the radiator and install the hose clamp (Refer to 7 - COOLING - OPERATION - HOSE CLAMPS).

(14) Install the coolant recovery container (Refer to 7 - COOLING/ENGINE/COOLANT RECOVERY CONTAINER - INSTALLATION).

(15) Reconnect the battery negative cable.

(16) Fill the engine cooling system (Refer to 7 - COOLING - STANDARD PROCEDURE - COOLING SYSTEM REFILLING)

(17) Evacuate the refrigerant system (Refer to 24 - HEATING & AIR CONDITIONING/PLUMBING - STANDARD PROCEDURE - REFRIGERANT SYSTEM EVACUATE).

(18) Charge the refrigerant system (Refer to 24 - HEATING & AIR CONDITIONING/PLUMBING - STANDARD PROCEDURE - REFRIGERANT SYSTEM CHARGE).

A/C DISCHARGE LINE

DESCRIPTION

The A/C discharge line is the refrigerant line that carries refrigerant from the A/C compressor to the A/C condenser. The A/C discharge line includes the high-side service port.

The A/C discharge line on models equipped with the 2.4L engine include a fitting for the A/C pressure transducer. For more information refer to 24 - HEATING & AIR CONDITIONING/CONTROLS/A/C PRESSURE TRANSDUCER - DESCRIPTION.

The A/C discharge line on models equipped with the 4.0L engine include a fitting for the A/C high pressure switch. For more information refer to 24 - HEATING & AIR CONDITIONING/CONTROLS/A/C HIGH PRESSURE SWITCH - DESCRIPTION.

CAUTION: Use only seals specified for the vehicle. Failure to use the correct seals will cause the refrigerant system connections to leak.

The A/C discharge line has no serviceable parts except for the O-ring seals and high-side service port valve and it's protective cap.

If the A/C discharge line is found to be leaking or is damaged, it must be replaced.

REMOVAL

2.4L ENGINE

WARNING: Refer to the applicable warnings and cautions for this system before performing the following operation (Refer to 24 - HEATING & AIR CONDITIONING/PLUMBING - WARNINGS) and (Refer to 24 - HEATING & AIR CONDITIONING/PLUMBING - CAUTIONS). Failure to follow the warnings and cautions could result in possible personal injury or death.

(1) Disconnect and isolate the negative battery cable.

(2) Recover the refrigerant from the refrigerant system (Refer to 24 - HEATING & AIR CONDITIONING/PLUMBING - STANDARD PROCEDURE - REFRIGERANT SYSTEM RECOVERY).

(3) Disconnect the wire harness connector from the A/C pressure transducer located on the A/C discharge line (Fig. 10).

(4) Remove the nut that secures the A/C discharge line to the A/C compressor.

(5) Disconnect the A/C discharge line from the A/C compressor and remove and discard the O-ring seal.

(6) Install plug in, or tape over the opened discharge line fitting and the compressor port.

(7) Remove the nut that secures theA/C discharge line to the A/C condenser.

(8) Disconnect the A/C discharge line from the A/C condenser and remove discard the O-ring seal.

(9) Install plug in, or tape over the opened discharge line fitting and the condenser port.