EVAPORATIVE EMISSIONS

TABLE OF CONTENTS

page

EVAPORATIVE EMISSIONS
DESCRIPTION - EVAPORATION CONTROL SYSTEM 10
SPECIFICATIONS
TORQUE - EMISSIONS 11
CCV SYSTEM
DESCRIPTION - CCV SYSTEM 11
OPERATION - CCV SYSTEM 11
DIAGNOSIS AND TESTING - CCV SYSTEM . . . 11
PCV VALVE
DESCRIPTION 12
OPERATION 12
REMOVAL 13
EVAP/PURGE SOLENOID
DESCRIPTION 13
OPERATION 13
REMOVAL 13
INSTALLATION 14
FUEL FILLER CAP
DESCRIPTION 14

page

OPERATION 14
REMOVAL 14
ORVR
DESCRIPTION 14
OPERATION 15
NATURAL VACUUM LEAK DETECTION ASSEMBLY
DESCRIPTION 16
OPERATION 16
REMOVAL 17
INSTALLATION 18
VACUUM LINES
DESCRIPTION 19
VAPOR CANISTER
DESCRIPTION 19
OPERATION 20
REMOVAL 20
INSTALLATION 20

EVAPORATIVE EMISSIONS

DESCRIPTION - EVAPORATION CONTROL SYSTEM

The evaporation control system prevents the emission of fuel tank vapors into the atmosphere. When fuel evaporates in the fuel tank, the vapors pass through vent hoses or tubes to a charcoal filled evaporative canister. The canister temporarily holds the vapors. The Powertrain Control Module (PCM) allows intake manifold vacuum to draw vapors into the combustion chambers during certain operating conditions.

All engines use a duty-cycle purge system. The PCM controls vapor flow by operating the duty-cycle EVAP purge solenoid. Refer to Duty-Cycle EVAP Canister Purge Solenoid.

An ORVR system is used. This system is part of the EVAP Control System. Refer to On-Board Refueling Vapor Recovery (ORVR) for information.

When equipped with certain emissions packages, a Leak Detection Pump (LDP) will be used as part of the evaporative system for OBD II requirements. Also refer to Leak Detection Pump.

NOTE: The evaporative system uses specially manufactured lines/hoses. If replacement becomes necessary, only use fuel resistant hose.