Group - 8 Electrical

Illustration Title — Group-Fig. No.

Starters
Starter [2.4L Engine] ..... Fig. 8 - 105
Starter [4.0L Engine] ..... Fig. 8 - 110

Alternators
Alternator 2.4L Engine ..... Fig. 8 - 205
Alternator 4.0L Engine ..... Fig. 8 - 210

Modules
Modules ..... Fig. 8 - 405

Relays
Power Distribution Center Relays and Fuses ..... Fig. 8 - 505
Fuse Block ..... Fig. 8 - 510

Sensors
Sensors 2.4L Engine [ED0] ..... Fig. 8 - 605
Sensors Engine 4.0L [ER0] ..... Fig. 8 - 610
Sensors, Oxygen 2.4L [ED0] ..... Fig. 8 - 615
Sensors Oxygen 4.0L [ER0] ..... Fig. 8 - 620
Sensors - Body ..... Fig. 8 - 625
Sensors Drive Train ..... Fig. 8 - 630

Single Board Engine Controllers
Single Board Engine Controllers (JTEC Module) ..... Fig. 8 - 705

Switches
Switches - Instrument Panel ..... Fig. 8 - 805
Switches Drivetrain ..... Fig. 8 - 810
Switches - Body ..... Fig. 8 - 815

Horns
Horns ..... Fig. 8 - 905

Battery Tray and Cables
Battery Tray & Cables ..... Fig. 8 - 1005
Engine Heaters ..... Fig. 8 - 1010

Lamps - Front, Rear and Courtesy
Lamps--Front ..... Fig. 8 - 1105
Lamps--Rear ..... Fig. 8 - 1110
Lamps--Cargo-Dome-Courtesy ..... Fig. 8 - 1115
Bulbs ..... Fig. 8 - 1120

Wiring-Engine & Related Parts
Wiring--Engine [2.4L Engine] ..... Fig. 8 - 1205
Wiring Engine [4.0L Engine] ..... Fig. 8 - 1210
Ground Straps ..... Fig. 8 - 1215

Wiring-Headlamp to Dash
Wiring--Headlamp / Dash Panel ..... Fig. 8 - 1305

Wiring-Instrument Panel
Wiring Instrument Panel & Fuses ..... Fig. 8 - 1405

Wiring-Body & Accessories
Wiring--Body & Accessory ..... Fig. 8 - 1505

Wiring Repair
Wiring Repair Packages ..... Fig. 8 - 1605

Air Bag Systems
Air Bag Modules and Sensors ..... Fig. 8 - 1705
Air Bags and Clock Springs ..... Fig. 8 - 1710

Spark Plugs-Cables-Coils
Spark Plugs--Cables--Coil ..... Fig. 8 - 1905