TABLE OF CONTENTS

1.0 INTRODUCTION 1

1.1 SYSTEM COVERAGE 1
1.2 SIX-STEP TROUBLE SHOOTING PROCEDURE 1

2.0 IDENTIFICATION OF SYSTEM 1

3.0 SYSTEM DESCRIPTION AND FUNCTIONAL OPERATION 2

3.1 GENERAL DESCRIPTION 2
3.2 FUNCTION OPERATION 2
3.2.1 FUEL CONTROL (GAS) 2
3.2.2 ON-BOARD DIAGNOSTICS 2
3.2.3 TRANSMISSION CONTROL 5
3.2.3.1 TRANSMISSION OPERATION AND SHIFT SCHEDULING AT VARIOUS OIL TEMPERATURES 5
3.2.4 O2 SENSOR (NGC) 6
3.2.5 OTHER CONTROLS 6
3.2.6 NON-MONITORED CIRCUITS 10
3.3 DIAGNOSTIC TROUBLE CODES 10
3.3.1 HARD CODE 11
3.3.2 ONE TRIP FAILURE 11
3.3.3 INTERMITTENT CODE 11
3.3.4 STARTS SINCE SET COUNTER 11
3.3.5 TROUBLE CODE ERASURE 12
3.3.6 QUICK LEARN 12
3.3.7 EATX DTC EVENT DATA 13
3.3.8 CLUTCH VOLUMES 13
3.3.9 NO START INFORMATION (POWERTRAIN) 13
3.4 USING THE DRBIII® 13
3.5 DRBIII® ERROR MESSAGES AND BLANK SCREEN 13
3.5.1 DRBIII® DOES NOT POWER UP 14
3.5.2 DISPLAY IS NOT VISIBLE 14
3.5.3 SOME DISPLAY ITEMS READ ″___″ 14
3.6 TRANSMISSION SIMULATOR (MILLER TOOL # 8333) AND ELECTRONIC TRANSMISSION ADAPTER KIT (MILLER TOOL #8333-1A) 14

4.0 DISCLAIMERS, SAFETY, WARNINGS 15

4.1 DISCLAIMERS 15
4.2 SAFETY 15
4.2.1 TECHNICIAN SAFETY INFORMATION 15
4.2.2 VEHICLE PREPARATION FOR TESTING 15
4.2.3 SEVICING SUB-ASSEMBLIES 15
4.2.4 DRBIII® SAFETY INFORMATION 15
4.3 WARNINGS AND CAUTIONS 16
4.3.1 ROAD TEST WARNINGS 16
4.3.2 VEHICLE DAMAGE WARNINGS 16
4.3.3 ROAD TESTING A COMPLAINT VEHCILE (TRANSMISSION) 16
4.3.4 ELECTRONIC PINION FACTOR WARNINGS (IF APPLICABLE) 17
4.3.5 SERVICE BULLETINS AND RECALLS 17