OBD II Monitor Operation

Comprehensive Components Monitor	Major Monitors Non Fuel Control & Non Misfire	Major Monitors Fuel Control & Misfire
Run constantly	Run Once Per Trip	Run constantly
Includes All Engine Hardware Sensors, Switches, Solenoids, etc.	Monitors Entire Emission System	Monitors Entire System
Most are One Trip Faults - Usually Turns On The MIL and Sets DTC After One Failure	Most are Two Trip Faults - Turns On The MIL and Sets DTC After Two Consecutive Failure	Two Trip Faults - Turns On The MIL and Sets DTC After Two Consecutive Failure
Priority 3	**Priority 1 or 3**	**Priority 2 or 4**
All Checked For Continuity Open Short To Ground Short To Voltage	Done Stop Testing = Yes Oxygen Sensor Heater Oxygen Sensor Response	**Fuel Control Monitor** Monitors Fuel Control System For: Fuel System Lean Fuel System Rich Requires 3 Consecutive *Fuel System Good Trips* to Extinguish the MIL
Inputs Checked For Rationality Outputs Checked For Functionality	Catalytic Converter Efficiency Except EWMA up to 6 tests per trip and a one trip fault (SBEC) and a two-trip fault on JTEC	
	EGR System Evaporative Emission System (Purge and Leak) Non-LDP or LDP	**Misfire Monitor** Monitors for Engine Misfire At: 4 X 1000 RPM Counter (4000 Revs) (Type B) **200 X 3 (600) RPM Counter (Type A)
Requires 3 Consecutive Good Trips to Extinguish the MIL*	Requires 3 Consecutive Good Trips to Extinguish the MIL*	Requires 3 Consecutive *Good Trips* To Extinguish the MIL
		**Type A misfire is a one trip failure on pre-1999, 2 Trip failure on 1999 and later. The MIL will illuminate at the first or second failure, based on MY.

***40 Warm Up Cycles** are required to erase DTCs after the MIL has been extinguished.