P0171-FUEL SYSTEM 1/1 LEAN — Continued

TEST	ACTION	APPLICABILITY
11	Only have one O2 Sensor disconnect at a time. With the DRBIII®, monitor all the O2 Sensor voltage readings. **NOTE: The DRBIII® will display all O2 Sensor voltage readings approximately 5.0 volts when only one O2 Sensor's Signal circuit is shorted to voltage.** **NOTE: The DRBIII® will display one O2 Sensor voltage close to zero and the others will read lower than normal when one O2 Sensor Signal circuit contains excessive resistance.** Is the voltage above 4.8 volts? Yes → Go To 12 No → Check all the O2 Signal circuits for a short to ground, open, or short to voltage. Inspect the O2 Sensor connector and the PCM harness connector. If OK, replace and program the Powertrain Control Module per Service Information. Perform POWERTRAIN VERIFICATION TEST VER - 5.	All
12	Disconnect each O2 Sensor harness connector. Measure the voltage on the O2 Return circuits in the O2 Sensor harness connector. **NOTE: The DRBIII® will display all O2 Sensor voltage readings approximately 5.0 volts when only one O2 Sensor's Return circuit is shorted to voltage.** **NOTE: The DRBIII® will display one O2 Sensor voltage close to zero and the others will read lower than normal when one O2 Sensor Return circuit contains excessive resistance.** Is the voltage at 2.5 volts? Yes → Replace and program the Powertrain Control Module per Service Information. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Check all the O2 Return circuits for a short to ground, open, or short to voltage. Inspect the O2 Sensor connector and the PCM harness connector. If OK, replace and program the Powertriain Control Module per Service Information. Perform POWERTRAIN VERIFICATION TEST VER - 5.	All
13	Turn the ignition off. **WARNING: The fuel system is under a constant pressure (even with the engine off). Before testing or servicing any fuel system hose, fitting or line, the fuel system pressure must be released.** Raise vehicle on hoist, and disconnect the fuel pressure line at the fuel pump module. Install special 5/16 fuel line adapter tool #6539 between disconnected fuel line and the fuel pump module. Attach a fuel pressure test gauge to the T fitting on tool #6539. Ignition on, engine not running. With the DRBIII®, actuate the ASD Fuel System test and observe the fuel pressure gauge. **NOTE: Fuel pressure specification is 407 KPa +/- 34 KPa (59 psi +/- 5 psi).** Is the fuel pressure within specification? Yes → Repair or replace fuel supply line as necessary. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 14 **CAUTION: Stop All Actuations.**	All