P0172-FUEL SYSTEM 1/1 RICH — Continued

TEST	ACTION	APPLICABILITY
9	Turn the ignition off. Disconnect the hoses at the Evap Purge Solenoid. Using a hand vacuum pump, apply 10 inches of vacuum to the Evap Purge Solenoid vacuum source port on the component side. Did the Evap Purge Solenoid hold vacuum? Yes → Go To 10 No → Replace the EVAP Purge Solenoid. Perform POWERTRAIN VERIFICATION TEST VER - 5. **NOTE: Connect the vacuum hoses before continuing.**	All
10	Check for any of the following conditions/mechanical problems. AIR INDUCTION SYSTEM - must be free from restrictions. ENGINE VACUUM - must be at least 13 inches in neutral ENGINE VALVE TIMING - must be within specifications ENGINE COMPRESSION - must be within specifications ENGINE EXHAUST SYSTEM - must be free of any restrictions or leaks. ENGINE PCV SYSTEM - must flow freely TORQUE CONVERTER STALL SPEED - must be within specifications POWER BRAKE BOOSTER - no internal vacuum leaks FUEL - must be free of contamination FUEL INJECTOR - plugged or restricted injector; control wire not connected to correct injector Are there any engine mechanical problems? Yes → Repair as necessary. Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 14	All
11	Ignition on, engine not running. **NOTE: Perform the following test on the O2 Sensors whose voltage was not switching properly in the previous step.** Disconnect the O2 Sensor harness connector. With the DRBIII®, monitor the O2 Sensor voltage. O2 Sensor voltage should read 5.0 volts on the DRBIII® with the connector disconnected. Connect a jumper wire between the O2 Signal circuit and the O2 Return circuit in the O2 Sensor harness connector. **NOTE: The voltage should drop from 5.0 volts down to 2.5 volts with the jumper wire connected.** Did the O2 Sensor voltage drop from 5.0 volts to 2.5 volts? Yes → Replace the O2 Sensor Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 12 **NOTE: Remove the jumper wire before continuing.**	All