## P0201-FUEL INJECTOR NO.1 CIRCUIT — Continued

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 3 | Using a 12-volt test light connected to 12-volts, backprobe the Injector Control circuit.<br>With the DRBIII®, actuate the Fuel Injector.<br>What is the state of the test light during the actuation?<br><br>Brightly blinking.<br>Replace the Fuel Injector.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5.<br><br>ON constantly.<br>Go To 4<br><br>OFF constantly.<br>Go To 5 | All |
| 4 | Turn the ignition off.<br>Disconnect the C2 PCM harness connector.<br>Measure the resistance between ground and the Injector Control circuit at the Injector harness connector.<br>Is the resistance below 100 ohms?<br><br>Yes → Repair the short to ground in the Injector Control circuit.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5.<br><br>No → Go To 6 | All |
| 5 | Turn the ignition off.<br>Disconnect the C2 PCM harness connector.<br>**CAUTION: DO NOT PROBE THE PCM HARNESS CONNECTORS. PROBING THE PCM HARNESS CONNECTORS WILL DAMAGE THE PCM TERMINALS RESULTING IN POOR TERMINAL TO PIN CONNECTION. INSTALL MILLER SPECIAL TOOL #8815 TO PERFORM DIAGNOSIS.**<br>Measure the resistance of the Injector Control circuit from the Fuel Injector harness connector to the appropriate terminal of special tool #8815.<br>Is the resistance below 5.0 ohms?<br><br>Yes → Go To 6<br><br>No → Repair the open in the Injector Control circuit.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5. | All |
| 6 | **NOTE: Before continuing, check the PCM harness connector terminals for corrosion, damage, or terminal push out. Repair as necessary.**<br>Using the schematics as a guide, inspect the wire harness and connectors. Pay particular attention to all Power and Ground circuits.<br>If there are no possible causes remaining, view repair.<br><br>Repair<br>Replace and program the Powertrain Control Module per Service Information.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5. | All |