## P0300-MULTIPLE CYLINDER MISFIRE — Continued

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 7 | **NOTE: Before continuing visually and physically inspect the fuel delivery system for external leaks or damage. Repair /replace as necessary.**<br>Turn the ignition off.<br>**WARNING: The fuel system is under a constant pressure even with the engine off. Before testing or servicing any fuel system hose, fitting or line, the fuel system pressure must be released.**<br>Install special tool #6539 (5/16″) or #6631 (3/8″) fuel line adapter.<br>Install the fuel pressure gauge.<br>Start the engine and allow the fuel system to reach maximum pressure.<br>Turn the ignition off.<br>**NOTE: Fuel specification is 407 KPa +/- 34 KPa (59 psi +/- 5 psi).**<br>Using special tool #C4390, Hose Clamp Pliers, pinch the rubber fuel line between the fuel pressure gauge and the engine.<br>Monitor the fuel pressure gauge for a minimum of 5 minutes.<br>**NOTE: The pressure should not fall below 241 KPa (35 psi)**<br>Does the Upstream gauge fall below the above specification?<br>Yes → Replace the leaking Fuel Injector(s).<br>Perform POWERTRAIN VERIFICATION TEST VER - 5.<br>No → Go To 8 | All |
| 8 | **Warning: The fuel system is under a constant pressure (even with the engine off). Before testing or servicing any fuel system hose, fitting or line, the fuel system pressure must be released.**<br>**CAUTION: After each Fuel Injector actuation, start the engine to clean the cylinder of fuel. Failure to do so could cause engine damage.**<br>Remove special tool #C4390.<br>Start the engine and allow the fuel pressure to reach maximum pressure.<br>Ignition on, engine not running.<br>Using the DRBIII®, actuate the Fuel Injector for the cylinder that indicated the misfire.<br>Monitor the fuel pressure gauge.<br>Does the fuel pressure gauge indicate a drop in fuel pressure?<br>Yes → Go To 9<br>No → Go To 10<br>**NOTE: Turn the ignition off, remove the Fuel Pressure gauge, and connect the fuel lines before continuing.** | All |
| 9 | Check for any of the following conditions/mechanical problems.<br>ENGINE VACUUM - must be at least 13 inches in neutral<br>ENGINE VALVE TIMING - must be within specifications<br>ENGINE COMPRESSION - must be within specifications<br>ENGINE EXHAUST SYSTEM - must be free of any restrictions or leaks.<br>ENGINE PCV SYSTEM - must flow freely<br>TORQUE CONVERTER STALL SPEED - must be within specifications<br>POWER BRAKE BOOSTER - no internal vacuum leaks<br>FUEL - must be free of contamination<br>CAM LOBES - must not be worn excessively<br>CYLINDER LEAKAGE TEST - must be within specifications<br>VALVE SPRINGS - cannot be weak or broken<br>Are there any engine mechanical problems?<br>Yes → Repair as necessary.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5.<br>No → Go To 16 | All |