Symptom List:

P0325-KNOCK SENSOR NO.1 CIRCUIT
P0330-KNOCK SENSOR NO.2 CIRCUIT

Test Note: All symptoms listed above are diagnosed using the same tests. The title for the tests will be P0325-KNOCK SENSOR NO.1 CIRCUIT.

When Monitored and Set Condition:

P0325-KNOCK SENSOR NO.1 CIRCUIT

When Monitored: With the engine running >1312 RPM, coolant temp >65.25°C (149.45°F), MAF >250mg/tdc and no ECT, MAF or CAM Sensor DTCs.

Set Condition: The Knock Sensor error program internal to the PCM is on, the Knock Sensor voltage is <.49 volt, and the value of the Knock Sensor changes less than .06 volt for >11 seconds. One Trip Fault. Three good trips to turn off the MIL.

P0330-KNOCK SENSOR NO.2 CIRCUIT

When Monitored: With the engine running >1312 RPM, coolant temp >65.25°C (149.45°F), MAF >250mg/tdc and no ECT, MAF or CAM Sensor DTCs.

Set Condition: The Knock Sensor error program internal to the PCM is on, the Knock Sensor voltage is <.49 volt, and the value of the Knock Sensor changes less than .06 volt for >11 seconds. One Trip Fault. Three good trips to turn off the MIL.

POSSIBLE CAUSES
GOOD TRIP EQUAL TO ZERO
KNOCK SENSOR SIGNAL CIRCUIT SHORTED TO VOLTAGE
KNOCK SENSOR SIGNAL CIRCUIT OPEN
KNOCK SENSOR RETURN CIRCUIT OPEN
KNOCK SENSOR SIGNAL CIRCUIT SHORTED TO GROUND
KNOCK SENSOR SIGNAL CIRCUIT SHORTED TO KNOCK SENSOR RETURN CIRCUIT
KNOCK SENSOR

TEST	ACTION	APPLICABILITY
1	Ignition on, engine not running. With the DRBIII®, read DTCs and record the related Freeze Frame data. Is the Good Trip Counter displayed and equal to zero? Yes → Go To 2 No → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 5.	All