P0440-GENERAL EVAP SYSTEM FAILURE — Continued

TEST	ACTION	APPLICABILITY
2	Check for any related TSBs before continuing. **NOTE: If any of the following DTCs are set (P0443, P0452, P0453, P0498 or P0499) diagnose them first before continuing with P0440.** **NOTE: A loose gas cap could have set this DTC to set. Make sure the gas cap is tight and in good condition.** Ignition on, engine not running. With the DRBIII®, read DTCs and record the related Freeze Frame data. Is the Good Trip Counter displayed and equal to zero? Yes → Go To 3 No → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 6.	All
3	Perform a visual and physical inspection of the entire Evaporative Emission system. Check for the following conditions: - Hoses disconnected or left off - Holes or cracks - Loose seal points - Evidence of damaged components - Incorrect routing of hoses and tubes - Fuel Cap left off or bad gasket seal Were any of the above conditions found? Yes → Repair as necessary. Perform POWERTRAIN VERIFICATION TEST VER - 6. No → Go To 4	All
4	Turn the ignition off. Carefully inspect the Evap Purge Solenoid vacuum supply hose for proper routing. Check for a pinched or plugged hose from the throttle body or intake manifold to the Purge Solenoid. Make sure the vacuum port at the throttle body is free from any blockage. Were any problems found? Yes → Repair the vacuum supply, hose/tube as necessary. Perform POWERTRAIN VERIFICATION TEST VER - 6. No → Go To 5	All