P0440-GENERAL EVAP SYSTEM FAILURE — Continued

TEST	ACTION	APPLICABILITY
5	To continue testing you will need Miller Tool #8404 Evaporative Emission Leak Detector (EELD). **WARNING: Keep lit cigarettes, sparks, flames, and other ignition sources away from the test area to prevent the ignition of explosive gases. Keep the test area well ventilated.** Connect the red power lead of EELD to the battery positive terminal and the black ground lead to battery negative terminal. Disconnect the vacuum hoses at he Evap Purge Solenoid. Connect the SMOKE supply tip (black hose) to the service port (if equipped) or to the #8404-ADP adapter. Set the smoke/air control switch to SMOKE. Press the remote smoke/air start button. **NOTE: Below is an optional method of checking the purge valve for leaks if the EELD is unavailable.** Turn the ignition off. Disconnect the vacuum supply hoses from the EVAP Purge Solenoid. Using a hand vacuum pump, apply 10 in Hg to the ″CAN″ side of the EVAP Purge Solenoid. Observe the vacuum gauge for at least 15 seconds. With the DRBIII®, actuate the Evap Purge Solenoid. **NOTE: If the Evap Purge Solenoid does not hold a vacuum, it will need to be replaced.** Is smoke visible from the Evap Purge Solenoid? Yes → Replace the Evap Purge Solenoid. Perform POWERTRAIN VERIFICATION TEST VER - 6. No → Go To 6	All
6	To continue testing you will need Miller Tool #8404 Evaporative Emission Leak Detector (EELD). **WARNING: Keep lit cigarettes, sparks, flames, and other ignition sources away from the test area to prevent the ignition of explosive gases. Keep the test area well ventilated.** Connect the red power lead of EELD to the battery positive terminal and the black ground lead to battery negative terminal. Disconnect the vacuum hoses at he Evap Purge Solenoid. Connect the SMOKE supply tip (black hose) to the service port (if equipped) or to the #8404-ADP adapter. Set the smoke/air control switch to SMOKE. Press the remote smoke/air start button. **NOTE: Below is an optional method of checking the purge valve for leaks if the EELD is unavailable.** Turn the ignition off. Disconnect the vacuum supply hoses from the EVAP Purge Solenoid. Using a hand vacuum pump, apply 10 in Hg to the ″CAN″ side of the EVAP Purge Solenoid. Observe the vacuum gauge for at least 15 seconds. With the DRBIII®, actuate the Evap Purge Solenoid. **NOTE: If the Evap Purge Solenoid does not hold a vacuum, it will need to be replaced.** Is smoke visible from the Evap Purge Solenoid? Yes → Replace the Evap Purge Solenoid. Perform POWERTRAIN VERIFICATION TEST VER - 6. No → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 6.	All