## P0441-EVAP PURGE SYSTEM PERFORMANCE — Continued

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 3 | **NOTE: After disconnecting the Evap Purge vacuum connections, inspect the lines and solenoid for any signs of contamination or foreign materials.**<br>Using a hand vacuum pump, apply 10 in Hg to ″CAN″ side of the EVAP Purge Solenoid.<br>Ignition on, engine not running.<br>Observe the vacuum gauge.<br>With the DRBIII®, actuate the EVAP Purge Solenoid .<br>Does the vacuum drop when the solenoid is actuated?<br>Yes → Go To 4<br>No → Replace the Evap Purge Solenoid.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5. | All |
| 4 | Turn the ignition off.<br>Carefully inspect the Evap Purge Solenoid vacuum supply hose for proper routing.<br>Check for a pinched or plugged hose from the throttle body to the Purge Solenoid.<br>Inspect the vacuum port at the throttle body for any damage or plugging.<br>Were any problems found?<br>Yes → Repair the vacuum supply hose/tube as necessary.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5.<br>No → Go To 5 | All |
| 5 | Connect the previously disconnected vacuum hoses.<br>Start the engine.<br>Allow the engine to idle.<br>Using the scan tool, perform the NVLD FORCED MONITOR TEST.<br>Monitor the NVLD Switch state.<br>**NOTE: As the test runs, the NVLD Switch should go from an OPEN to a CLOSED state and then return to OPEN when the test is complete. This may take up to 10 minutes.**<br>Did the NVLD Switch operate as described above?<br>Yes → Test complete.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5.<br>No → Go To 6 | All |
| 6 | Perform the NVLD FORCED MONITOR TEST for the second time.<br>While the NVLD FORCED MONITOR TEST is running, open/remove the gas cap.<br>Did the NVLD Switch go from OPEN to CLOSED?<br>Yes → Replace the NVLD Assembly.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5.<br>Test Complete.<br>Test Complete. | All |