P0457-LOOSE FUEL FILL CAP — Continued

TEST	ACTION	APPLICABILITY
2	**NOTE: After the PCM has determined the leak test inconclusive and sees an increase in fuel level, the PCM will request the GAS CAP indicator on to inform the customer that the gas fill cap is loose or off.** Ignition on, engine not running. With the DRBIII®, read DTCs and record the related Freeze Frame data. Is the Good Trip Counter displayed and equal to zero? Yes → Go To 3 No → Refer to the INTERMITTENT CONDITION symptom in the Driveability category. Perform POWERTRAIN VERIFICATION TEST VER - 6.	All
3	Perform a visual and physical inspection of the Fuel Fill Cap and the fill tube. Check for the follow conditions: - Improper installation of Fuel Fill Cap - Loose or missing Fuel Filler Cap - Holes or cracks - Damaged Locking tabs on Cap and/or fill tube - Damaged seal points on Cap and/or fill tube - Fuel Fill Cap gasket seal Were any of the above conditions found? Yes → Repair or replace the fuel fill cap as needed. Ensure proper fuel fill cap installation. Once the repair is complete continue to step 3. Perform POWERTRAIN VERIFICATION TEST VER - 6. No → Go To 4	All
4	With the DRBIII®, perform the NVLD Service Test. Did the NVLD Service Test pass? Yes → Test Complete. Perform POWERTRAIN VERIFICATION TEST VER - 6. No → Go To 5	All