## Symptom:

## P0461-FUEL LEVEL SENSOR NO.1 PERFORMANCE

**When Monitored and Set Condition:**

**P0461-FUEL LEVEL SENSOR NO.1 PERFORMANCE**

When Monitored: TEST #1: With the ignition on, the fuel level is compared to the previous key down after a 20 second delay. TEST #2: The PCM monitors the fuel level at ignition on.

Set Condition: TEST #1: If the PCM does not see a difference in fuel level of greater than 0.1 volt the test will fail. TEST #2: If the PCM does not see a change in the fuel level of .1765 over a set amount of miles the test will fail.

| POSSIBLE CAUSES |
|---|
| GOOD TRIP EQUAL TO ZERO |
| VISUALLY INSPECT FUEL TANK |
| (N4) FUEL LEVEL SIGNAL CIRCUIT OPEN |
| (N4) FUEL LEVEL SIGNAL CIRCUIT SHORTED TO GROUND |
| (K900) SENSOR GROUND CIRCUIT OPEN |
| INTERNAL INSPECTION OF THE FUEL TANK |
| FUEL LEVEL SENSOR |

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 1 | **NOTE: Diagnose P0462 or P0463 first, if set along with P0461.**<br>**NOTE: Inspect the Fuel Pump Module harness connector for any corrosion or damage.**<br>Ignition on, engine not running.<br>With the DRBIII®, read DTCs and record the related Freeze Frame data.<br>Is the Good Trip Counter displayed and equal to zero?<br>Yes → Go To 2<br>No → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure).<br>Perform POWERTRAIN VERIFICATION TEST VER - 5. | All |
| 2 | Visually inspect the Fuel Tank for damage that may restrict the Fuel Sending Unit float from moving.<br>Is the Fuel Tank OK?<br>Yes → Go To 3<br>No → Replace the Fuel Tank as necessary.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5. | All |