## P0481-COOLING FAN NO.2 CONTROL CIRCUIT — Continued

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 3 | Ignition on, engine not running.<br>Using a 12-volt test light connected to ground, probe the (F20) Fused Ignition Switch Output circuit at the Relay connector in the PDC.<br>Does the test light illuminate brightly?<br><br>Yes → Go To 4<br><br>No → Repair the open or short to ground in the (F20) Fused Ignition Output. Inspect the related fuse and repair as necessary.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5. | All |
| 4 | Using a 12-volt test light connected to ground probe the (A16) Fused B+ circuit in the PDC.<br>Does the test light illuminate brightly?<br><br>Yes → Go To 5<br><br>No → Repair the open or short to ground (A16) Fused B+ circuit. Inspect the related fuse and repair as necessary.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5. | All |
| 5 | Turn the ignition off.<br>Disconnect the C3 PCM harness connector.<br>Measure the resistance of the (N112) High Speed Rad Fan Relay Control circuit from the PDC to the PCM harness connector.<br>Is the resistance below 5.0 ohms?<br><br>Yes → Go To 6<br><br>No → Repair the open in the (N112) High Speed Rad Fan Relay Control circuit.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5. | All |
| 6 | Measure the resistance between ground and the (N112) High Speed Rad Fan Relay Control circuit in the PDC.<br>Is the resistance below 5.0 ohms?<br><br>Yes → Repair the short to ground in the (N112) High Speed Rad Fan Relay Control circuit.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5.<br><br>No → Go To 7 | All |
| 7 | **NOTE: Before continuing, check the PCM harness connector terminals for corrosion, damage, or terminal push out. Repair as necessary.**<br>Using the schematics as a guide, inspect the wire harness and connectors. Pay particular attention to all Power and Ground circuits.<br>If there are no possible causes remaining, view repair.<br><br>Repair<br>Replace and program the Powertrain Control Module per Service Information.<br>Perform POWERTRAIN VERIFICATION TEST VER - 5. | All |