Symptom:

P0562-BATTERY VOLTAGE LOW

When Monitored and Set Condition:

P0562-BATTERY VOLTAGE LOW

When Monitored: The engine running. The engine speed greater than 380 RPM.

Set Condition: Battery voltage is 1 volt less than desired system voltage.

POSSIBLE CAUSES
GOOD TRIP EQUAL TO ZERO
BATTERY POSITIVE CIRCUIT HIGH RESISTANCE
GENERATOR GROUND HIGH RESISTANCE
GENERATOR OPERATION
(K125) GEN FIELD CONTROL CIRCUIT OPEN
(K125) GEN FIELD CONTROL CIRCUIT SHORTED TO GROUND
(Z20) GROUND CIRCUIT OPEN
PCM

TEST	ACTION	APPLICABILITY
1	**NOTE: Make sure the Battery is in good condition. Using the Midtronics Battery Tester, test the Battery before continuing.** **NOTE: Inspect the vehicle for after market accessories that may exceed the Generator System output.** Turn the ignition off. **NOTE: Make sure the generator drive belt is in good operating condition.** **NOTE: Inspect the fuses in the PDC. If a fuse is found to be open use the wiring diagram/schematic as a guide, inspect the wiring and connectors for damage.** Ignition on, engine not running. With the DRBIII®, read DTCs and record the related Freeze Frame data. Is the Good Trip Counter displayed and equal to zero? Yes → Go To 2 No → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 3.	All