P0562-BATTERY VOLTAGE LOW — Continued

TEST	ACTION	APPLICABILITY
2	**WARNING: WHEN THE ENGINE IS OPERATING, DO NOT STAND IN A DIRECT LINE WITH THE FAN. DO NOT PUT YOUR HANDS NEAR THE PULLEYS, BELTS OR FAN. DO NOT WEAR LOOSE CLOTHING.** Ignition on, engine not running. **NOTE: Make sure all wires are clear of the engine's moving parts.** Start the engine. Allow the engine to reach normal operating temperature. Measure the voltage between the Generator B+ Terminal and the Battery + Post. Is the voltage above 0.4 of a volt? Yes → Repair the Battery Positive circuit for high resistance between the Generator and Battery. Perform POWERTRAIN VERIFICATION TEST VER - 3. No → Go To 3	All
3	**WARNING: WHEN THE ENGINE IS OPERATING, DO NOT STAND IN A DIRECT LINE WITH THE FAN. DO NOT PUT YOUR HANDS NEAR THE PULLEYS, BELTS OR FAN. DO NOT WEAR LOOSE CLOTHING.** **NOTE: Make sure all wires are clear of the engine's moving parts.** Measure the voltage between the Generator case and Battery ground post. Is the voltage above 0.1 of a volt? Yes → Repair Generator Ground for high resistance, Generator Case to Battery ground side. Perform POWERTRAIN VERIFICATION TEST VER - 3. No → Go To 4	All
4	Turn the ignition off. Disconnect the Generator Field harness connector. Use a 12-volt test light and jump it across the Generator Field harness connector. Ignition on, engine not running. With the DRBIII®, actuate the Generator Field Control circuit. Does the test light illuminate brightly and flash on and off? Yes → Replace the Generator. Perform POWERTRAIN VERIFICATION TEST VER - 3. No → Go To 5	All
5	Turn the ignition off. Disconnect the C2 PCM harness connector. **CAUTION: DO NOT PROBE THE PCM HARNESS CONNECTORS. PROBING THE PCM HARNESS CONNECTORS WILL DAMAGE THE PCM TERMINALS RESULTING IN POOR TERMINAL TO PIN CONNECTION. INSTALL MILLER SPECIAL TOOL #8815 TO PERFORM DIAGNOSIS.** Measure the resistance of the (K125) Gen Field Control circuit from the Generator Field harness connector to the appropriate terminal of the special tool #8815. Is the resistance below 5.0 ohms? Yes → Go To 6 No → Repair the open in the (K125) Gen Field Control circuit. Perform POWERTRAIN VERIFICATION TEST VER - 3.	All