Symptom:

P0594-SPEED CONTROL SERVO POWER CIRCUIT

When Monitored and Set Condition:

P0594-SPEED CONTROL SERVO POWER CIRCUIT

When Monitored: Engine running, the speed control switched on and learned, and the brake pedal is not pressed. No other fault has occured this trip.

Set Condition: The speed control power supply circuit is either open or shorted to ground. Cruise will be disabled for the remainder of that key-on cycle. One Trip Fault. Three good trips to clear the MIL.

POSSIBLE CAUSES
GOOD TRIP EQUAL TO ZERO
(V32) S/C SUPPLY CIRCUIT OPEN
(V32) S/C SUPPLY CIRCUIT SHORTED TO GROUND
BRAKE LAMP SWITCH
(V30) S/C BRAKE SWITCH OUTPUT
(V30) S/C BRAKE SWITCH OUPUT CIRCUIT OPEN
(V30) S/C BRAKE SWITCH OUTPUT CIRCUIT SHORTED TO GROUND
PCM

TEST	ACTION	APPLICABILITY
1	Ignition on, engine not running. With the DRBIII®, read DTCs and record the related Freeze Frame data. Is the Good Trip Counter equal to zero? Yes → Go To 2 No → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 4.	All
2	Disconnect the Brake Lamp Switch harness connector. Start the engine. Using a 12-volt test light connected to ground, probe the (V32) S/C Supply circuit in the Switch harness connector while holding the Cruise Switch in the ON position. Does the test light illuminate brightly? Yes → Go To 3 No → Go To 7	All