P0594-SPEED CONTROL SERVO POWER CIRCUIT — Continued

TEST	ACTION	APPLICABILITY
3	Turn the ignition off. Disconnect and remove the Brake Lamp Switch. Measure the resistance across the (V32) S/C Supply circuit terminal and the (V30) S/C Brake Switch Output circuit terminal at the Brake Lamp Switch. Push the Plunger of the Switch in and let it out. Does the resistance change from below 5.0 ohms to an open circuit? Yes → Go To 4 No → Replace the Brake Lamp Switch. Perform POWERTRAIN VERIFICATION TEST VER - 4.	All
4	Turn the ignition off. Connect the Brake Lamp Switch harness connecter and install the Switch. Disconnect the Speed Control Servo harness connector. Ignition on, engine not running. **NOTE: It is necessary to PRESS and HOLD the Speed Control Switch in the ON position while checking for voltage.** Using a 12-volt test light connected to ground, probe the (V30) S/C Brake Switch Output circuit in the Servo Harness connector. Does the test light illuminate brightly? Yes → Replace the S/C Servo. Perform POWERTRAIN VERIFICATION TEST VER - 4. No → Go To 5	All
5	Turn the ignition off. Disconnect the Brake Lamp Switch harness connector. Measure the resistance of the (V30) S/C Brake Switch Output circuit from the Brake Lamp Switch harness connector to the S/C Servo harness connector. Is the resistance below 5.0 ohms? Yes → Repair the excessive resistance in the (V30) S/C Brake Switch Output circuit. Perform POWERTRAIN VERIFICATION TEST VER - 4. No → Go To 6	All
6	Measure the resistance between ground and the (V30) S/C Brake Switch Output circuit at the Speed Control Servo harness connector. Is the resistance below 100 ohms? Yes → Repair the short to ground in the (V30) S/C Brake Switch Output circuit. Perform POWERTRAIN VERIFICATION TEST VER - 4. No → Go To 9	All