Symptom:

P0627-FUEL PUMP RELAY CIRCUIT

When Monitored and Set Condition:

P0627-FUEL PUMP RELAY CIRCUIT

When Monitored: With the ignition on. Battery voltage greater than 10.4 volts.

Set Condition: An open or shorted condition is detected in the fuel pump relay control circuit.

POSSIBLE CAUSES
FUEL PUMP RELAY OPERATION
(F1) FUSED IGNITION SWITCH OUTPUT CIRCUIT
(A930) FUSED B+ CIRCUIT
FUEL PUMP RELAY
(K31) FUEL PUMP RELAY CONTROL CIRCUIT OPEN
(K31) FUEL PUMP RELAY CONTROL CIRCUIT SHORTED TO GROUND
PCM

TEST	ACTION	APPLICABILITY
1	Ignition on, engine not running. With the DRBIII®, actuate the Fuel Pump Relay. Is the Fuel Pump Relay operating? Yes → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 5. No → Go To 2	All
2	Turn the ignition off. Remove the Fuel Pump Relay from the PDC. Ignition on, engine not running. Using a 12-volt test light connected to ground, probe the (F1) Fused Ignition Switch Output circuit in the PDC. Does the test light illuminate brightly? Yes → Go To 3 No → Repair the (F1) Fused Ignition Switch Output circuit. Inspect the related fuse. An open fuse may have been caused by a short to ground. Perform POWERTRAIN VERIFICATION TEST VER - 5.	All