Symptom:

P0645-A/C CLUTCH RELAY CIRCUIT

When Monitored and Set Condition:

P0645-A/C CLUTCH RELAY CIRCUIT

When Monitored: With the ignition on. Battery voltage greater than 10 volts. A/C Switch on.

Set Condition: An open or shorted condition is detected in the A/C clutch relay control circuit. The desired A/C state does not equal the actual A/C clutch relay state. Three good trips to clear the MIL.

POSSIBLE CAUSES
A/C CLUTCH RELAY OPERATION
(F960) FUSED IGNITION SWITCH OUTPUT CIRCUIT
(A926) FUSED B+ CIRCUIT
A/C CLUTCH RELAY
(C13) A/C CLUTCH RELAY CONTROL CIRCUIT OPEN
(C13) A/C CLUTCH RELAY CONTROL CIRCUIT SHORTED TO GROUND
PCM

TEST	ACTION	APPLICABILITY
1	Ignition on, engine not running. With the DRBIII®, actuate the A/C Clutch Relay. Is the A/C Clutch Relay operating? Yes → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 2. No → Go To 2	All
2	Turn the ignition off. Remove the A/C Clutch Relay from the PDC. Ignition on, engine not running. Using a 12-volt test light connected to ground, probe the (F960) Fused Ignition Switch Output circuit. Does the test light illuminate brightly? Yes → Go To 3 No → Repair the open or short to ground in the (F960) Fused Ignition Switch Output circuit. Inspect and replace any open fuses. Perform POWERTRAIN VERIFICATION TEST VER - 2.	All