P0850-PARK/NEUTRAL SWITCH PERFORMANCE — Continued

TEST	ACTION	APPLICABILITY
3	Measure the resistance between ground and the TRS T41 Sense (P/N Sense) circuit at the TRS harness connector. Is the resistance above 100k ohms? Yes → Go To 4 No → Repair the short to ground in the TRS T41 Sense (P/N Sense) circuit. Perform POWERTRAIN VERIFICATION TEST VER - 2.	All
4	Connect the Transmission Range Sensor harness connector. Move the Gear selector through all gear positions, from Park to 1st and back. While moving the gear selector through each gear, measure the resistance between ground and the TRS T41 Sense (P/N Sense) circuit using special tool #8815. **NOTE: The circuit is grounded in Park and Neutral and open in the other positions.** Did the resistance change from above 100 kohms (open) to below 10.0 ohms (grounded)? Yes → Go To 5 No → Replace the Transmission Range Sensor. Perform POWERTRAIN VERIFICATION TEST VER - 2.	All
5	**NOTE: Before continuing, check the PCM harness connector terminals for corrosion, damage, or terminal push out. Repair as necessary.** Using the schematics as a guide, inspect the wire harness and connectors. Pay particular attention to all Power and Ground circuits. If there are no possible causes remaining, view repair. Repair Replace and program the Powertrain Control Module per Service Information. Perform POWERTRAIN VERIFICATION TEST VER - 2.	All