Symptom:
U0101-NO BUS MESSAGE FROM TRANS CONTROL MODULE

When Monitored and Set Condition:

U0101-NO BUS MESSAGE FROM TRANS CONTROL MODULE

When Monitored: Equipped with automatic transmission. The ignition on. Battery voltage greater than 10 volts.

Set Condition: An open circuit on the (F11) Fused Igniton Switch Output circuit. No bus messages from the TCM for 20 seconds, two trips required.

POSSIBLE CAUSES
DTC RESET
PCM FUSED IGNITION SWITCH OUTPUT CIRCUIT
PCI BUS UNABLE TO COMMUNICATE WITH DRBIII®
PCM

TEST	ACTION	APPLICABILITY
1	Ignition on, engine not running. With the DRBIII®, erase DTCs. Cycle the ignition key on and off several times. Leaving the ignition on for at least 20 seconds. With the DRBIII®, read DTCs. Does the DTC reset? Yes → Go To 2 No → Refer to the INTERMITTENT CONDITION Symptom (Diagnostic Procedure). Perform POWERTRAIN VERIFICATION TEST VER - 1.	All
2	Turn the ignition off. Disconnect the PCM harness connectors. **CAUTION: DO NOT PROBE THE PCM HARNESS CONNECTORS. PROBING THE PCM HARNESS CONNECTORS WILL DAMAGE THE PCM TERMINALS RESULTING IN POOR TERMINAL TO PIN CONNECTION. INSTALL MILLER SPECIAL TOOL #8815 TO PERFORM DIAGNOSIS.** With a 12-volt test light connected to ground and with special tool #8815 installed, probe the (F11) Fused Ignition Switch Output circuit. Perform the above check with the Ignition key in the off lock position, Ignition on, engine not running position, and during cranking. Wiggle the related wire harness while probing the special tool with the test light to try to interrupt the circuit. Does the test light illuminate brightly? Yes → Go To 3 No → Repair the open or excessive resistance in the (F11) Fused Ignition Switch (Offf, Run, Start) circuit. Inspect the related fuse, if the fuse is open check the circuit for a short to ground. Perform POWERTRAIN VERIFICATION TEST VER - 1.	All