*CHECKING A/C SYSTEM OPERATION WITH NO DTCS — Continued

TEST	ACTION	APPLICABILITY
10	Engine Running. Turn the A/C system on and the fan on high. With the DRBIII® in Inputs/Outputs, read the A/C request state. Does the A/C request state change? Yes → Go To 11 No → Repair the open in the A/C Request circuit. Perform POWERTRAIN VERIFICATION TEST VER - 2.	All
11	Turn the ignition off. Remove the A/C Clutch Relay. **Note: Check connectors - Clean/repair as necessary.** Measure the voltage of the (A17) Fused B+ circuit at the A/C Clutch Relay connector. Is the voltage above 11.0 volts? Yes → Go To 12 No → Repair the open in the (A17) Fused B+ circuit. Perform POWERTRAIN VERIFICATION TEST VER - 2.	All
12	If there are no possible causes remaining, view repair. Repair Replace the A/C Clutch Relay. Perform POWERTRAIN VERIFICATION TEST VER - 2.	All
13	Turn the ignition off. Disconnect the A/C - Heater Control C1 harness connector. Ignition on, engine not running. Measure the voltage between the A/C On/Off Control circuit and ground. Is the voltage greater than 11.0 volts? Yes → Go To 14 No → Go To 15	All
14	Turn the ignition off. Disconnect the A/C - Heater Control C1 harness connector. Ignition on, engine not running. With the DRBIII® in BCM, select Inputs/Outputs. Monitor the A/C Select Switch state while connecting a jumper wire between ground and the A/C On/Off Control circuit in the A/C - Heater Control C1 harness connector. Does the A/C Select Switch state change from ″Off″ to ″On″ when the jumper wire is connected. Yes → Replace the A/C - Heater Control Module in accordance with the Service Information. Perform BODY VERIFICATION TEST - VER 1. No → Replace and program the Body Control Module per Service Information. Perform BODY VERIFICATION TEST - VER 1.	All