P0562-LOW BATTERY VOLTAGE — Continued

TEST	ACTION	APPLICABILITY
2	With the DRBIII®, read the PCM DTC's. Are there any Charging System related DTC's stored in the PCM? Yes → Refer to the Charging System category and repair any PCM Charging System DTC's first. NOTE: After repairing the PCM charging system DTC's, perform the Transmission Verification test to verify the transmission was not damaged. Perform 42RLE TRANSMISSION VERIFICATION TEST - VER 1. No → Go To 3	All
3	**NOTE: Generator, battery, and charging system must be fully functional before performing this test.** With the DRBIII®, read Transmission DTC's. With the DRBIII®, Check the STARTS SINCE SET counter for P0562. **Note: This counter only applies to the last DTC set.** Is the Starts Since Set counter for P0562 set at 0? Yes → Go To 4 No → Go To 9	All
4	Turn the ignition off to the lock position. Disconnect the TCM harness connector. **Note: Check connectors - Clean/repair as necessary.** Using a 12-volt test light connected to 12-volts, check the ground circuits in the TCM harness connector. **NOTE: The test light must illuminate brightly. Compare the brightness to that of a direct connection to the battery.** Does the test light illuminate brightly for all the ground circuits? Yes → Go To 5 No → Repair the Ground circuit(s) for an open or high resistance. Perform 42RLE TRANSMISSION VERIFICATION TEST - VER 1.	All
5	Turn the ignition off to the lock position. Disconnect the TCM harness connector. Remove the Transmission Control Relay. **Note: Check connectors - Clean/repair as necessary.** Connect a jumper wire between the Fused B+ circuit and the Transmission Control Relay Output in the Transmission Control Relay connector in the PDC. Ignition on, engine not running. Using a 12-volt test light connected to ground, check the Fused B+ circuit in the TCM harness connector. **NOTE: The test light must illuminate brightly. Compare the brightness to that of a direct connection to the battery.** Does the test light illuminate brightly? Yes → Go To 6 No → Repair the Fused B+ circuit for an open or high resistance. If the fuse is open make sure to check for a short to ground. Perform 42RLE TRANSMISSION VERIFICATION TEST - VER 1.	All