P0706-CHECK SHIFTER SIGNAL — Continued

TEST	ACTION	APPLICABILITY
4	Turn the ignition off to the lock position. **CAUTION: Remove the Starter Relay from the PDC. This will prevent the vehicle from being started in gear.** Install the Transmission Simulator, Miller tool #8333 and the Electronic Transmission Adapter kit 8333-1A. Ignition on, engine not running. With the DRBIII®, perform the Shift Lever Position Test. When the DRBIII ® instructs you to put the Gear Selector in a particular position, you must do so using the Transmission Simulator. The LED for the gear position in question must be illuminated prior to hitting ″enter″ on the DRBIII®. Did the test pass? Yes → Go To 5 No → Go To 6 **NOTE: Disconnect the Transmission Simulator and reconnect all the harness connectors.**	All
5	If there are no possible causes remaining, view repair. Repair Replace the Transmission Range Sensor per the Service Information. Perform 42RLE TRANSMISSION VERIFICATION TEST - VER 1.	All
6	Ignition on, engine not running. With the DRBIII® in Inputs/Outputs, read the TRS Sense circuits C1 thru C4. Move the shift lever thru all gear positions, pausing momentarily in each gear position. Watch for one of the circuits to not change state. Pick the one that did not change state. TRS T1 sense (C4) Go To 7 TRS T3 sense (C3) Go To 10 TRS T41 sense (C1) Go To 13 TRS T42 sense (C2) Go To 16	All
7	Turn the ignition off to the lock position. Disconnect the TRS harness connector. Disconnect the TCM harness connector. **Note: Check connectors - Clean/repair as necessary.** Measure the resistance of the TRS T1 Sense circuit from the TCM harness connector to the TRS harness connector. Is the resistance above 5.0 ohms? Yes → Repair the TRS T1 Sense circuit for an open. Perform 42RLE TRANSMISSION VERIFICATION TEST - VER 1. No → Go To 8	All