## Symptom:

### P0740-TCC OUT OF RANGE

**When Monitored and Set Condition:**

**P0740-TCC OUT OF RANGE**

When Monitored: During Electronically Modulated Converter Clutch (EMCC) Operation.

Set Condition: A) Transmission must be in EMCC, with input speed > than 1750 RPM. TCC/L-R sol achieves the maximum duty cycle & can't pull engine RPM within 60 RPM of input speed. B) Transmissions is in FEMCC & engine slips TCC > than 100 RPM for 10 seconds.

| POSSIBLE CAUSES |
|---|
| RELATED DTC'S PRESENT |
| INTERNAL TRANSMISSION |
| INTERMITTENT WIRING AND CONNECTORS |

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 1 | **NOTE: Low fluid level can be the cause of many Transmission problems. If the fluid level is low, locate and repair the leak, then check and adjust the fluid level per the Service Information.**<br>**NOTE: Always perform diagnostics with a fully charged battery to avoid false symptoms.**<br>With the DRBIII®, read the engine DTC's. Check and repair all engine DTC's prior to performing Transmission Symptom Diagnostics.<br>With the DRBIII®, read Transmission DTC's. Record all DTC's and 1 Trip Failures.<br>**NOTE: Diagnose 1 Trip Failures as a fully matured DTC.**<br>Using the wiring diagram/schematic as a guide, inspect the wiring and connectors. Repair as necessary.<br>Perform the Shift Lever Position Test. If the test does not pass, refer to Symptom test for P0706 Check Shifter Signal.<br>For Gear Ratio DTC's, check and record all CVI's.<br>Most DTC's set on start up but some must be set by driving the vehicle such that all diagnostic monitors have run.<br>**NOTE: Verify flash level of Transmission Control Module. Some problems are corrected by software upgrades to the Transmission Control Module.**<br>**NOTE: Check for applicable TSB's related to the symptom.**<br>Perform this procedure prior to Symptom diagnosis.<br><br>Continue<br>Go To 2 | All |
| 2 | Ignition on, engine not running.<br>With the DRBIII®, read Transmission DTC's<br>Is the DTC P0750 and/or P0841 present also?<br><br>Yes → Refer to the Transmission category and perform the appropriate symptom.<br>Perform 42RLE TRANSMISSION VERIFICATION TEST - VER 1.<br><br>No → Go To 3 | All |