Symptom List:

P0882-TCM POWER INPUT LOW
P0888-RELAY OUTPUT ALWAYS OFF

Test Note: All symptoms listed above are diagnosed using the same tests. The title for the tests will be P0882-TCM POWER INPUT LOW.

When Monitored and Set Condition:

P0882-TCM POWER INPUT LOW

When Monitored: Continuously

Set Condition: This DTC is set when less than 3 volts are present at the Transmission Control Relay output circuits at the Transmission Control Module (TCM) when the TCM is energizing the relay. Note: Due to the integration of the Powertrain and Transmission Control Modules, the transmission part of the PCM has its own specific power and ground circuits.

P0888-RELAY OUTPUT ALWAYS OFF

When Monitored: Continuously

Set Condition: This code is set when less than 3 volts are present at the transmission control relay output circuits at the Transmission Control Module when the TCM is energizing the relay.

POSSIBLE CAUSES
FUSED B+ CIRCUIT OPEN
TRANSMISSION CONTROL RELAY GROUND CIRCUIT OPEN
INTERMITTENT WIRING AND CONNECTORS