P0882-TCM POWER INPUT LOW — Continued

TEST	ACTION	APPLICABILITY
4	Turn the ignition off to the lock position. Remove the Transmission Control Relay. **Note: Check connectors - Clean/repair as necessary.** Using a 12-volt test light connected to 12-volts, check the Transmission Control Relay Ground circuit. **NOTE: The test light must illuminate brightly. Compare the brightness to that of a direct connection to the battery.** Does the test light illuminate brightly? Yes → Test Complete. No → Repair the Transmission Control Relay Ground circuit for an open or high resistance. Perform 42RLE TRANSMISSION VERIFICATION TEST - VER 1.	All
5	The conditions necessary to set this DTC are not present at this time. Using the schematics as a guide, inspect the wiring and connectors specific to this circuit. Wiggle the wiring while checking for shorts and open circuits. With the DRBIII®, check the EATX EVENT DATA to help identify the conditions in which the DTC was set. Were there any problems found? Yes → Repair as necessary. Perform 42RLE TRANSMISSION VERIFICATION TEST - VER 1. No → Test Complete.	All