## P0890-SWITCHED BATTERY — Continued

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 3 | Turn the ignition off to the lock position.<br>Disconnect the TCM harness connector.<br>Disconnect the Transmission Solenoid/Pressure Switch Assembly harness connector.<br>Remove the Transmission Control Relay.<br>**Note: Check connectors - Clean/repair as necessary.**<br>Connect a jumper wire between the Fused B+ circuit and the Transmission Control Relay Output circuit in the Transmission Control Relay connector.<br>Ignition on, engine not running.<br>Measure the voltage of the 2/4 Pressure Switch Sense circuit.<br>Is the voltage above 0.5 volt?<br>Yes → Repair the 2/4 Pressure Switch Sense circuit for a short to voltage. Perform 42RLE TRANSMISSION VERIFICATION TEST - VER 1.<br>No → Go To 4 | All |
| 4 | Turn the ignition off to the lock position.<br>Disconnect the TCM harness connector.<br>Disconnect the Transmission Solenoid/Pressure Switch Assembly harness connector.<br>Remove the Transmission Control Relay from the PDC.<br>**Note: Check connectors - Clean/repair as necessary.**<br>Connect a jumper wire between the Fused B+ circuit and the Transmission Control Relay Output circuit in the Transmission Control Relay connector.<br>Ignition on, engine not running.<br>Measure the voltage of the L/R Pressure Switch Sense circuit.<br>Is the voltage above 0.5 volt?<br>Yes → Repair the L/R Pressure Switch Sense circuit for a short to voltage. Perform 42RLE TRANSMISSION VERIFICATION TEST - VER 1.<br>No → Test Complete. | All |
| 5 | The conditions necessary to set this DTC are not present at this time.<br>Using the schematics as a guide, inspect the wiring and connectors specific to this circuit.<br>Wiggle the wiring while checking for shorts and open circuits.<br>With the DRBIII®, check the EATX EVENT DATA to help identify the conditions in which the DTC was set.<br>Were there any problems found?<br>Yes → Repair as necessary. Perform 42RLE TRANSMISSION VERIFICATION TEST - VER 1.<br>No → Test Complete. | All |