## P1687-NO COMMUNICATION WITH THE MIC — Continued

| TEST | ACTION | APPLICABILITY |
|---|---|---|
| 4 | Ignition on, engine not running.<br>With the DRBIII®, erase TCM DTC's.<br>Start the engine in park.<br>With the DRBIII®, read Transmission DTC's.<br>Is the DTC, P1687- No Communication with the MIC, present?<br><br>Yes → Replace the Transmission Control Module per the Service Information. WITH THE DRBIII® PERFORM QUICK LEARN. Perform 42RLE TRANSMISSION VERIFICATION TEST - VER 1.<br><br>No → Test Complete. | All |
| 5 | The conditions necessary to set this DTC are not present at this time.<br>Using the schematics as a guide, inspect the wiring and connectors specific to this circuit.<br>Wiggle the wiring while checking for shorts and open circuits.<br>With the DRBIII®, check the EATX EVENT DATA to help identify the conditions in which the DTC was set.<br>Were there any problems found?<br><br>Yes → Repair as necessary. Perform 42RLE TRANSMISSION VERIFICATION TEST - VER 1.<br><br>No → Test Complete. | All |