Symptom:

*TRANSMISSION NOISY WITH NO DTC'S PRESENT

POSSIBLE CAUSES
INCORRECT FLUID LEVEL
INTERNAL TRANSMISSION PROBLEM - NOISY
INTERNAL TRANSMISSION PROBLEM - NOISY WHILE STANDING STILL

TEST	ACTION	APPLICABILITY
1	Check the Transmission Fluid Level per the Service Information. Is the fluid level OK? Yes → Go To 2 No → Adjust fluid level and repair cause of incorrect fluid level. Perform TRANSMISSION NO TROUBLE CODE VERIFICATION TEST.	All
2	Place vehicle on hoist. **WARNING: BE SURE TO KEEP HANDS AND FEET CLEAR OF ROTATING WHEELS.** Run vehicle on hoist under conditions necessary to duplicate the noise. **NOTE: It may be necessary to test drive the vehicle to duplicate the noise.** Using Chassis Ears or other suitable listening device, verify the source of the noise. Is the noise coming from the transmission? Yes → Go To 3 No → Test Complete.	All
3	With the shift lever in neutral, raise the engine speed and listen to the noise. **NOTE: THE RADIO MUST BE TURNED OFF. Alternator noise can come through the speakers and be misinterpreted as Transmission Pump Whine. This can happen even with the volume turned down.** Does the noise get louder or change pitch while the engine speed is changing? Yes → Go To 4 No → Go To 5	All
4	If there are no possible causes remaining, view repair. Repair Repair internal transmission problem as necessary. Inspect all of the transmission components for signs of wear. If no problems found, replace the Transmission oil pump.. Perform TRANSMISSION NO TROUBLE CODE VERIFICATION TEST.	All
5	If there are no possible causes remaining, view repair. Repair Repair internal transmission problem as necessary. Inspect all of the transmission components for signs of wear. Pay particular attention to bearings, pinion gears, etc. Repair or replace as necessary. Perform TRANSMISSION NO TROUBLE CODE VERIFICATION TEST.	All