Verification Tests

42RLE (NGC) TRANSMISSION VERIFICATION TEST - VER 1	APPLICABILITY
1. NOTE: After completion of the Transmission Verification Test, the Powertrain Verification Test must be performed. Refer to the Powertrain Category. 2. Connect the DRBIII® to the Data Link Connector (DLC). 3. Reconnect any disconnected components. 4. With the DRBIII®, erase all Transmission DTC's, also erase Engine DTC's. **5. NOTE: If the Transmission Control Module or Torque Converter has been replaced, or if the Transmission has been repaired or replaced, it is necessary to perform the DRBIII® Quick Learn Procedure and reset the "Pinion Factor".** 6. Perform *PRNDL FAULT CLEARING PROCEDURE after completion of repairs for P0706 CHECK SHIFTER SIGNAL. 7. With the DRBIII®, display Transmission Temperature. Start and run the engine until the Transmission Temperature is HOT, above 43° C or 110° F. 8. Check the transmission fluid and adjust if necessary. Refer to the Service Information for the Fluid Fill procedure. **9. NOTE: Erase DTC P0700 under Engine to turn off the MIL light after completing transmission repairs.** 10. If the Torque converter has been replaced, with the scan tool perform TCC BREAK-IN. 11. Road test the vehicle. With the DRBIII®, monitor the engine RPM. Make 15 to 20 1-2, 2-3, 3-4 upshifts. Perform these shifts from a standing start to 45 MPH with a constant throttle opening of 20 to 25 degrees. 12. Below 25 MPH, make 5 to 8 wide open throttle kickdowns to 1st gear. Allow at least 5 seconds each in 2nd and 3rd gear between each kickdown. 13. For a specific DTC, drive the vehicle to the Symptom's When Monitored/When Set conditions to verify the DTC is repaired. 14. If equipped with AutoStick®, upshift and downshift several times using the AutoStick® feature during the road test. **15. NOTE: Use the OBDII task manager to run a Good Trip in each gear, this will confirm the repair and to ensure that the DTC has not re-matured.** 16. Check for Diagnostic Trouble Codes (DTCs) during and after the road test. **17. NOTE: Erase P0700 DTC in the PCM to turn the MIL light off after making transmission repairs.** Did any DTCs set during or after the road test? Yes → Repair is not complete, refer to the appropriate symptom. Perform 42RLE (NGC) TRANSMISSION VERIFICATION TEST - VER 1. No → Repair is complete.	All