A/C COMPRESSOR CLUTCH RELAY

CAV	CIRCUIT	FUNCTION
A6	F960 20PK/LG	FUSED IGNITION SWITCH OUTPUT (RUN-START)
A7	-	-
A8	C13 18LB/OR	A/C CLUTCH RELAY CONTROL
A9	C3 20DB/YL	A/C CLUTCH RELAY OUTPUT
A10	A926 20RD	FUSED B(+)

AUTOMATIC SHUT DOWN RELAY

CAV	CIRCUIT	FUNCTION
A11	K342 18BR/WT (EXCEPT FED ABS)	ASD RELAY CONTROL
A11	K51 18BR/WT (FED ABS)	ASD RELAY CONTROL
A12	-	-
A13	F1 20PK/WT (EXCEPT FED ABS)	FUSED IGNITION SWITCH OUTPUT (RUN-START)
A13	F1 20PK/WT (EXCEPT FED ABS)	FUSED IGNITION SWITCH OUTPUT (RUN-START)
A13	F22 20PK/TN (FED ABS)	FUSED IGNITION SWITCH OUTPUT (RUN-START)
A14	K334 14BR (FED ABS)	ASD RELAY OUTPUT
A15	A209 18RD/YL (EXCEPT FED ABS)	FUSED B(+)
A15	A14 18RD/YL (FED ABS)	FUSED B(+)

ENGINE STARTER MOTOR RELAY

CAV	CIRCUIT	FUNCTION
B1	A8 14RD	FUSED B(+)
B2	T750 14YL/GY	ENGINE STARTER MOTOR RELAY OUTPUT
B3	T752 18DG/OR	STARTER MOTOR RELAY CONTROL
B4	-	-
B5	F26 16PK/OR (EXCEPT FED ABS)	IGNITION SWITCH OUTPUT (START)
B5	F22 18PK/TN (FED ABS)	IGNITION SWITCH OUTPUT (START)

FUEL PUMP RELAY

CAV	CIRCUIT	FUNCTION
C6	F1 20PK/WT (EXCEPT FED ABS)	FUSED IGNITION SWITCH OUTPUT (RUN-START)
C6	F1 20PK/WT (EXCEPT FED ABS)	FUSED IGNITION SWITCH OUTPUT (RUN-START)
C6	F22 20PK/TN (FED ABS)	FUSED IGNITION SWITCH OUTPUT (RUN-START)
C7	-	-
C8	K31 18BR	FUEL PUMP RELAY CONTROL
C9	A109 18OR/RD	FUEL PUMP RELAY OUTPUT
C10	A930 18RD (EXCEPT FED ABS)	FUSED B(+)
C10	A930 18RD/BK (FED ABS)	FUSED B(+)

HIGH SPEED RADIATOR FAN RELAY (2.4L)

CAV	CIRCUIT	FUNCTION
D10	A16 12GY	FUSED B(+)
D11	N24 12DG/DB	HIGH SPEED RADIATOR FAN RELAY CONTROL
D13	F102 20PK/DB	FUSED IGNITION SWITCH OUTPUT (RUN)
D13	F102 20PK/DB	FUSED IGNITION SWITCH OUTPUT (RUN)
D14	N201 18DB/LG	HIGH SPEED RADIATOR RELAY OUTPUT