
Group – 008
Electrical



008–100 Starters	**008–200** Alternators	**008–400** Modules	**008–500** Relays
008–600 Sensors	**008–700** Single Board Engine Controllers	**008–800** Switches	**008–900** Horns

Group – 008
Electrical

008–1000 Battery Tray and Cables	**008–1100** Lamps – Front, Rear and Courtesy	**008–1200** Wiring–Engine & Related Parts	**008–1300** Wiring–Headlamp to Dash
008–1400 Wiring–Instrument Panel	**008–1500** Wiring–Body & Accessories	**008–1600** Wiring Repair WIRING REPAIR PKG.	**008–1700** Air Bag Systems
008–1900 Spark Plugs–Cables–Coils			