TABLE OF CONTENTS

1.0 INTRODUCTION 1

1.1 SYSTEM COVERAGE 1
1.2 SIX-STEP TROUBLESHOOTING PROCEDURE 1

2.0 IDENTIFICATION OF SYSTEM 1

3.0 SYSTEM DESCRIPTION AND FUNCTIONAL OPERATION 1

3.1 AIRBAG SYSTEM 1
3.1.1 PASSENGER AIRBAG ON-OFF SWITCH 2
3.1.2 SPECIAL TOOLS 3
3.1.3 DIAGNOSTIC TROUBLE CODES 3
3.1.3.1 ACTIVE CODES 3
3.1.3.2 STORED CODES 3
3.2 AUDIO SYSTEM 4
3.3 ELECTROCHROMIC COMPASS/TEMPERATURE MIRROR WITH LIGHTS 4
3.4 ELECTRICALLY HEATED SYSTEMS 7
3.4.1 REAR WINDOW DEFOGGER 7
3.5 ELECTRO/MECHANICAL INSTRUMENT CLUSTER (EMIC) 7
3.5.1 SMART CLUSTER FEATURES 7
3.5.2 INSTRUMENT CLUSTER SELF TEST 8
3.6 VEHICLE COMMUNICATION 8
3.7 USING THE DRBIII® 9
3.7.1 DRBIII® ERROR MESSAGES AND BLANK SCREEN 9
3.7.2 DRBIII® DOES NOT POWER UP 9
3.7.3 DISPLAY IS NOT VISIBLE 10

4.0 DISCLAIMERS, SAFETY, WARNING 10

4.1 DISCLAIMERS 10
4.2 SAFETY 10
4.2.1 TECHNICIAN SAFETY INFORMATION 10
4.2.2 VEHICLE PREPARATION FOR TESTING 10
4.2.3 SERVICING SUB-ASSEMBLIES 10
4.2.4 DRBIII® SAFETY INFORMATION 10
4.3 WARNINGS 11
4.3.1 VEHICLE DAMAGE WARNINGS 11
4.3.2 ROAD TESTING A COMPLAINT VEHICLE 11

5.0 REQUIRED TOOLS AND EQUIPMENT 11

6.0 GLOSSARY OF TERMS 11

7.0 DIAGNOSTIC INFORMATION AND PROCEDURES 13

AIRBAG
ACCELEROMETER 1 14
INTERNAL 1 14
OUTPUT DRIVER 1 14
SAFING SENSOR 14
STORED ENERGY FIRING 1 14
STORED ENERGY LOGIC 14
AIRBAG WARNING INDICATOR OPEN 16